

Machine Automation Controller NJ/NX-series

# Motion Device Connection Guide (EtherCAT<sup>®</sup> Connection)

## SANYO DENKI CO.,LTD.

AC Servo Amplifier

SANMOTION R ADVANCED MODEL

TYPE F

EtherCAT Interface Type H



Network  
Connection  
Guide

### **About Intellectual Property Rights and Trademarks**

---

Microsoft product screen shots reprinted with permission from Microsoft Corporation.

Windows is a registered trademark of Microsoft Corporation in the USA and other countries.

EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.

Sysmac is a trademark or registered trademark of OMRON Corporation in Japan and other countries for OMRON factory automation products.

Company names and product names in this guide are the trademarks or registered trademarks of their respective companies.

---

## Table of Contents

|   |           |
|---|-----------|
| <b>1. Related Manuals</b> .....   | <b>1</b>  |
| <b>2. Terms and Definitions</b> .....   | <b>3</b>  |
| <b>3. Precautions</b> .....   | <b>5</b>  |
| <b>4. Overview</b> .....  | <b>6</b>  |
| <b>5. Applicable Devices and Device Configuration</b> .....                               | <b>7</b>  |
| 5.1. Applicable Devices .....   | 7         |
| 5.2. Device Configuration .....   | 8         |
| <b>6. EtherCAT Settings</b> .....   | <b>10</b> |
| 6.1. Parameters .....   | 10        |
| 6.2. Relationship Between Motion Control via EtherCAT and its<br>Parameter Settings ..... | 15        |
| <b>7. EtherCAT Connection Procedure</b> .....   | <b>16</b> |
| 7.1. Work Flow .....  | 16        |
| 7.2. Preparation for Controller Setup .....   | 18        |
| 7.3. SANYO DENKI Servo Amplifier Setup .....  | 26        |
| 7.4. Controller Setup .....   | 43        |
| 7.5. Connection Status Check .....  | 63        |
| <b>8. Restrictions on Motion Control</b> .....  | <b>69</b> |
| 8.1. List of Restrictions .....   | 69        |
| 8.2. Axis Variable .....  | 70        |
| 8.3. MC Instruction .....   | 70        |
| 8.4. Others .....   | 71        |
| <b>9. Appendix 1: Procedures Using the Project File</b> .....                             | <b>72</b> |
| 9.1. Work Flow .....  | 72        |
| 9.2. Controller Setup .....   | 73        |
| <b>10. Appendix 2: MC Instructions and PDO Entries</b> .....                              | <b>79</b> |
| 10.1. Required Objects for MC Instructions .....  | 79        |
| 10.2. Required Objects for Specific MC Instructions .....                                 | 80        |
| 10.3. Digital Inputs Assignment .....   | 81        |
| <b>11. Appendix 3: Program</b> .....  | <b>82</b> |
| 11.1. MC Instruction .....  | 82        |
| 11.2. Program (ST Language) .....   | 83        |
| <b>12. Revision History</b> .....   | <b>85</b> |

## 1. Related Manuals

To ensure system safety, make sure to always read and follow the information provided in all Safety Precautions and Precautions for Safe Use in the manuals for each device which is used in the system.

The table below lists the manuals provided by SANYO DENKI CO., LTD. (hereinafter referred to as "SANYO DENKI") and OMRON Corporation (hereinafter referred to as "OMRON"), which pertain to this guide.

| Manufacturer | Cat. No. | Model                                  | Manual name   |
|--------------|----------|--|---|
| OMRON        | W500     | NJ501-□□□□<br>NJ301-□□□□<br>NJ101-□□□□ | NJ-series CPU Unit<br>Hardware User's Manual  |
| OMRON        | W535     | NX701-□□□□                             | NX-series CPU Unit<br>Hardware User's Manual  |
| OMRON        | W593     | NX102-□□□□                             | NX-series<br>NX102 CPU Unit<br>Hardware User's Manual   |
| OMRON        | W578     | NX1P2-□□□□                             | NX-series<br>NX1P2 CPU Unit<br>Hardware User's Manual   |
| OMRON        | W501     | NX701-□□□□<br>NX102-□□□□               | NJ/NX-series CPU Unit<br>Software User's Manual   |
| OMRON        | W502     | NX1P2-□□□□<br>NJ501-□□□□               | NJ/NX-series<br>Instructions Reference Manual   |
| OMRON        | W505     | NJ301-□□□□<br>NJ101-□□□□               | NJ/NX-series<br>CPU Unit Built-in EtherCAT® Port<br>User's Manual                                   |
| OMRON        | W507     |  | NJ/NX-series CPU Unit<br>Motion Control User's Manual   |
| OMRON        | W508     |  | NJ/NX-series<br>Motion Control Instructions<br>Reference Manual                                     |
| OMRON        | W503     |  | NJ/NX-series<br>Troubleshooting Manual  |
| OMRON        | W504     | SYSMAC-SE2□□□                          | Sysmac Studio Version 1<br>Operation Manual   |
| OMRON        | I576     | R88M-K□<br>R88D-KN□-ECT                | AC SERVOMOTORS/SERVO DRIVES<br>G5-series WITH BUILT-IN EtherCAT®<br>COMMUNICATIONS<br>User's Manual |

| Manufacturer   | Cat. No. | Model      | Manual name   |
|----------------|----------|------------|---|
| SANYO<br>DENKI | M0011195 | RF2□□□□H□□ | SANMOTION AC SERVO SYSTEMS<br>R ADVANCED MODEL TYPE F<br>with EtherCAT Interface Type H<br>For Rotary Motor, Linear Motor<br>Instruction Manual |
| SANYO<br>DENKI | M0010842 | —          | MOTOR SETUP SOFTWARE<br>SERVO SYSTEMS<br>Instruction Manual   |

## 2. Terms and Definitions

The terms and definitions used in this guide are given below.

| Term   | Explanation and Definition   |
|--|--|
| slave unit   | A generic name for a device that performs EtherCAT communications with an EtherCAT master. There are various types of slave units such as servo drives that handle position data and I/O terminals that handle bit signals.  |
| object   | An object consists of information such as data and parameters within a slave unit. .   |
| PDO communications<br>(Communications using<br>Process Data Objects) | One type of EtherCAT communications in which process data objects (PDOs) are used to exchange information in a fixed cycle and realtime. It is also called process data communications.  |
| SDO communications<br>(Communications using<br>Service Data Objects) | One type of EtherCAT communications. It is a communications method in which EtherCAT communications instructions are used to read and write specified data (SDO data) between an EtherCAT master and slaves whenever required.   |
| PDO mapping  | Association of objects used for PDO communications.  |
| PDO entry  | A pointer to an object used for PDO mappings.  |
| function module  | One of the functional units of the software configuration of a CPU Unit  |
| Motion Control<br>Function Module                                    | One of the function modules. This module performs motion control according to the commands from motion control instructions that are executed in a user program. It sends data to the EtherCAT Master Function Module. (Abbreviation: MC Function Module)  |
| EtherCAT Master<br>Function Module                                   | One of the function modules. This function module communicates with EtherCAT slaves as an EtherCAT master.   |
| PLC<br>Function Module   | One of the function modules. This module manages overall scheduling, executes a user program, sends commands to the MC Function Module, and provides interfaces to a USB/SD memory card.   |
| motion control<br>instruction  | An instruction that is defined as a function block to execute a motion control function.<br><br>There are two types of motion control instructions: one is based on function blocks for PLCopen® motion control and the other is specifically developed for the MC Function Module. (Abbreviation: MC instruction)   |
| PLCopen®   | PLCopen® is an association that promotes IEC 61131-3.<br>It has its headquarters in Europe and a world-wide membership.<br>PLCopen® standardizes function blocks for motion control to define a program interface for the languages specified in IEC 61131-3.<br>PLCopen® headquarter website: <a href="http://www.plcopen.org/">http://www.plcopen.org/</a> |
| axis   | A functional unit within the MC Function Module. An axis is assigned to the drive mechanism in an external servo drive or the sensing mechanism in an external encoder input slave unit.   |

| Term   | Explanation and Definition   |
|--|--|
| axis variable                                    | A system-defined variable that is defined as a structure and provides status information and some of the axis parameters for an individual axis. An axis variable is used to specify an axis for MC instructions and to monitor the command position, error information, and other information for the axis. |
| ESI file<br>(EtherCAT Slave<br>Information file) | An ESI file contains information unique to EtherCAT slave units in XML format. You can load an ESI file into the Sysmac Studio, to allocate EtherCAT slave process data and make other settings.   |

## 3. Precautions

- (1) Understand the specifications of devices which are used in the system. Allow some margin for ratings and performance. Provide safety measures, such as installing a safety circuit, in order to ensure safety and minimize the risk of abnormal occurrence.
- (2) To ensure system safety, make sure to always read and follow the information provided in all Safety Precautions and Precautions for Safe Use in the manuals for each device which is used in the system.
- (3) The user is encouraged to confirm the standards and regulations that the system must conform to.
- (4) It is prohibited to copy, to reproduce, and to distribute a part or the whole of this guide without the permission of OMRON Corporation.
- (5) The information contained in this guide is current as of October 2018. It is subject to change for improvement without notice.

The following notations are used in this guide.



**WARNING**

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury, or may result in serious injury or death. Additionally there may be significant property damage.



**Caution**

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury or property damage.



### Precautions for Correct Use

Precautions on what to do and what not to do to ensure proper operation and performance.



### Additional Information

Additional information to read as required.

This information is provided to increase understanding or make operation easier.

### Symbol



The filled circle symbol indicates operations that you must do. The specific operation is shown in the circle and explained in the text. This example shows a general precaution for something that you must do.

## 4. Overview

This guide describes procedures for connecting and operating a SANYO DENKI AC Servo Amplifier SANMOTION R ADVANCED MODEL TYPE F with EtherCAT Interface Type H (hereinafter referred to as the "Servo Amplifier") using a motion control instruction (hereinafter referred to as an "MC instruction") for an OMRON NJ/NX-series Machine Automation Controller (hereinafter referred to as the "Controller"), as well as for checking the connection status.

The explanations given in this guide assume the use of NX-series Controllers.

The Servo Amplifier is also referred to as the "Motion Control Device" or "slave unit" in some descriptions.

Refer to *Section 6. EtherCAT Settings* and *Section 7. EtherCAT Connection Procedure* to understand setting methods and key points to operate the Motion Control Device using EtherCAT PDO communications. The MC\_Power (Power Servo) is given as an example of an MC instruction to check the operation in this guide.

The operation of motion control varies depending on the device you use. Make sure that you understand *Section 8. Restrictions on Motion Control* before you design a system.

### Caution

The scope of this guide covers the "connection check of the Motion Control Device connected via EtherCAT using the MC\_Power instruction". To use MC instructions and design a system not described in this guide, make sure to always read and follow the information provided in all Safety Precautions and Precautions for Safe Use in the manuals for each device you intend to use in the system. Please note that some functions of the MC Function Module may be unavailable, or available but different in behavior from OMRON Motion Control Devices due to the different specifications between non-OMRON and OMRON Motion Control Devices. Make sure to check *Section 8. Restrictions on Motion Control* in this guide when you design a system.



#### Additional Information

Both the settings and the operation check program described in *7.4. Controller Setup* are made in advance in the Sysmac Studio project file (hereinafter referred to as "the project file") specified below. Refer to *Section 9. Appendix 1: Procedures Using the Project File* for information on how to use the project file.

Obtain the project file with a latest version from OMRON Corporation.

The project file specified below has been created for NX-series Controllers. If you use NJ-series Controllers, change the device information displayed in the Change Device Dialog Box of Sysmac Studio.

| Name  | File name                            | Version  |
|---|--------------------------------------|----------|
| Sysmac Studio project file<br>(extension: csm2) | P707_NX_ECATCH_SanyoDK_RF2_V100.csm2 | Ver.1.00 |

## 5. Applicable Devices and Device Configuration

### 5.1. Applicable Devices

The applicable devices are as follows:

| Manufacturer   | Name   | Model  |
|----------------|--|--|
| OMRON          | NJ/NX-series CPU Unit                                      | NX701-17□□<br>NX701-16□□<br>NX1P2-11□□□□<br>NX1P2-10□□□□<br>NX1P2-90□□□□<br>NJ501-□□□□<br>NJ301-12□□<br>NJ301-11□□<br>NJ101-10□□ |
| SANYO<br>DENKI | Servo Amplifier Type F                                     | RF2□□□□H□□   |
| SANYO<br>DENKI | Servo Motors for Type F<br>(Rotary Motor and Linear Motor) | —  |



#### Precautions for Correct Use

In this guide, the devices with models and versions listed in 5.2. *Device Configuration* are used as examples of applicable devices to describe the procedures for connecting the devices and checking their connection.

You cannot use devices with versions lower than the versions listed in 5.2.

To use the above devices with models not listed in 5.2. or versions higher than those listed in 5.2., check the differences in the specifications by referring to the manuals before operating the devices.



#### Additional Information

This guide describes the procedures for establishing the network connection.

It does not provide information on operation, installation, wiring method, device functionality, or device operation, which is not related to the connection procedures.

Refer to the manuals or contact the device manufacturer.




#### Additional Information

Contact SANYO DENKI CO., LTD. for Servo Motors connectable to Servo Amplifiers.

**5.2. Device Configuration**

This guide describes the connection procedures using an NX-series Controller.  
 The hardware components to reproduce the connection procedures are shown below.  
 In this guide, only one axis of the Servo Amplifier is used to connect the Servo Motor.



| Manufacturer   | Name  | Model           | Version            |
|----------------|---|-----------------|--------------------|
| OMRON          | NX series CPU Unit<br>(Built-in EtherNet/IP port)                                     | NX102-1200      | Ver.1.30           |
| —              | Power supply<br>for the Controller (24 VDC)   | —               | /                  |
| OMRON          | Sysmac Studio   | SYSMAC-SE2□□□   | Ver.1.23           |
| —              | Personal computer<br>(OS: Windows 10)   | —               | /                  |
| —              | LAN cable (STP (shielded,<br>twisted-pair) cable of Ethernet<br>category 5 or higher) | —               | /                  |
| OMRON          | Ethernet cable (with industrial<br>Ethernet connector)                                | XS5W-T421-□M□-K | /                  |
| SANYO<br>DENKI | Servo Amplifier   | RF2K24A0HL5     | Rev.0x0000<br>0000 |
| SANYO<br>DENKI | Servo Motor   | R2GA02D20FXC00  | /                  |
| SANYO<br>DENKI | ESI file  | P0010959C01.xml | /                  |
| SANYO<br>DENKI | SANMOTION Motor Setup   | —               | Ver.1.13           |
| SANYO<br>DENKI | PC communication cable  | AL-00689703-01  | /                  |
| —              | Control power supply (24 VDC)   | —               | /                  |
| —              | Main circuit power supply (48 VDC)  | —               | /                  |



**Precautions for Correct Use**

Prepare the ESI file specified above beforehand.  
 To obtain the ESI file, contact SANYO DENKI CO., LTD.



### Precautions for Correct Use

---

The connection line of EtherCAT communications cannot be shared with other Ethernet networks. Do not use devices for Ethernet such as a switching hub.

Use an Ethernet cable (double shielding with aluminum tape and braiding) of Category 5 or higher, and use a shielded connector of Category 5 or higher.

Connect the cable shield to the connector hood at both ends of the cable.

---



### Precautions for Correct Use

---

Update Sysmac Studio to the version specified on the previous page or to a higher version.

If you use a version higher than the one specified, the procedures and related screenshots described in *Section 7.* and the subsequent sections may not be applicable. In that case, use the equivalent procedures described in this guide by referring to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504).

---



### Additional Information

---

For information on specifications of Ethernet cables and network wiring, refer to *Section 4. EtherCAT Network Wiring* of the *NJ/NX-series CPU Unit Built-in EtherCAT® Port User's Manual* (Cat. No. W505).

---



### Additional Information

---

For information on power supply specifications of the Controller, refer to the *NX-series NX102 CPU Unit Hardware User's Manual* (Cat. No. W593).

---



### Additional Information

---

For information on power supply specifications of the Servo Amplifier, refer to the *SANMOTION AC SERVO SYSTEMS R ADVANCED MODEL TYPE F with EtherCAT Interface Type H For Rotary Motor, Linear Motor Instruction Manual* (M0011195).

---



### Additional Information

---

The scope of this guide covers the "connection check of the Motion Control Device connected via EtherCAT using the MC\_Power instruction"; hence, a regenerative resistor is not used. If you connect a regenerative resistor, refer to *4.1 Control power supply, Regeneration resistance, and Wiring protective ground* and *12.2 Capacity Selection of Regenerative Resistor* of the *SANMOTION AC SERVO SYSTEMS R ADVANCED MODEL TYPE F with EtherCAT Interface Type H For Rotary Motor, Linear Motor Instruction Manual* (M0011195).

---

## 6. EtherCAT Settings

This section describes the parameter settings for EtherCAT communications and motion control that are defined in this guide, and explains the relationship between motion control via EtherCAT and its parameter settings.

### 6.1. Parameters

The parameters set in this guide are shown below.

Those parameters are set based on the connection using only Ax1 (axis) of the Servo Amplifier.

#### 6.1.1. EtherCAT Communications Settings

The Servo Amplifier and Controller parameters required for EtherCAT communications are shown below. Use the following settings when you perform 7.3.1. *Hardware Settings* and 7.3.2. *Parameter Settings*.

##### Hardware settings

| Setting item                 |     | Servo Amplifier | Remarks                    |
|------------------------------|-----|-----------------|----------------------------|
| Station alias address (ADDR) | HI  | 0               | Set the node address to 1. |
|                              | LOW | 1               |                            |

##### Parameter settings

| Setting item  | Controller                       | Servo Amplifier  |     |     |     |                          |                          |                          |
|---|----------------------------------|--|-----|-----|-----|--------------------------|--------------------------|--------------------------|
|   |                                  | Ax1  | Ax2 | Ax3 | Ax4 |                          |                          |                          |
| Enable distributed clock (SM2 Sync mode <sup>*1</sup> ) | Enabled (DC-Synchronous (SYNC0)) | 0002: SYNC0 Event Synchronization (Synchronized with SYNC0 Hardware Signal)(Default) | /   |     |     |                          |                          |                          |
| Combined motor code                                     |                                  | 0x049B (Motor model: R2GA02D20F)   |     |     |     |                          |                          |                          |
| Combined sensor resolution setting                      |                                  | 0x0002 (1,000 P/R)   |     |     |     |                          |                          |                          |
| Combined sensor type                                    |                                  | 0x0101 (Asynchronous encoder (incremental system) 2.5 MHz without multi turn output) |     |     |     |                          |                          |                          |
| Enable axis setting                                     |                                  | 01: Enabled (Default)  |     |     |     | 00: Disabled             | 00: Disabled             | 00: Disabled             |
| Flag for the axis between the interlock mask            |                                  | 10: Disable (Default) <sup>*2</sup>  |     |     |     | 00: Enable <sup>*3</sup> | 00: Enable <sup>*3</sup> | 00: Enable <sup>*3</sup> |
| Positive limit switch function                          |                                  | 00: Always_Disable (Default)   |     |     |     | —                        | —                        | —                        |
| Negative limit switch function                          |                                  | 00: Always_Disable (Default)   |     |     |     | —                        | —                        | —                        |
| Emergency stop function                                 |                                  | 0C:CONT6_ON <sup>*4</sup>  |     |     |     | —                        | —                        | —                        |

\*1 This parameter is set for Ax1.

\*2 No emergency stop (EMR) state even when an error is detected at the other axes.

\*3 Emergency stop (EMR) state when an error is detected at the other axes.

\*4 The emergency stop function is enabled when general input CONT6 is ON.

### 6.1.2. PDO Mapping

To use motion control functions, you must map the objects that are required for those functions to PDOs.

The PDO entries (objects) used in this guide are shown below.

Use the settings when you perform 7.4.2. *PDO Map Settings*.



#### Precautions for Correct Use

##### Restrictions on PDO Mapping

The following restrictions are imposed on PDO mapping for the Servo Amplifier.

- The number of objects which can be mapped, are maximum 10 objects per axis for input and output respectively.
- The size of objects are maximum 32 bytes per axis for input and output respectively.
- Must set the mapping data size per axis as even-bytes for input and output respectively.

If the data is odd byte, add 1 bit by using Padding object (OD:0x0000 SI:0) to make an even-byte.

For more information on the restrictions on PDO mapping, refer to 2) *PDO Mapping* in 5.3 *CoE Communication Area of the SANMOTION AC SERVO SYSTEMS R ADVANCED MODEL TYPE F With EtherCAT Interface Type H For Rotary Motor, Linear Motor Instruction Manual (M0011195)*



#### Additional Information

For more information relating to 6.1.2. *PDO Mapping* and 6.1.5. *Axis Settings for PDO Entries*, refer to Section 10. *Appendix 2: MC Instructions and PDO Entries*.

Output (Controller to Servo Amplifier)

Ax1

| PDO Map                          |              |              |          | PDO entries included in Outputs(Ax1) |          |           |                       |         |
|----------------------------------|--------------|--------------|----------|--------------------------------------|----------|-----------|-----------------------|---------|
| Selection                        | Input/Output | Name         | Flag     | Index                                | Size     | Data type | PDO entry name        | Comment |
| <input type="radio"/>            | ---          | No option    | ---      | 0x6040:00                            | 16 [bit] | UINT      | Control word          |         |
| <input type="radio"/>            | Output       | Outputs(Ax1) | Editable | 0x607A:00                            | 32 [bit] | DINT      | Target position       |         |
| <input checked="" type="radio"/> | Output       | Outputs(Ax1) | Editable | 0x607F:00                            | 32 [bit] | DINT      | Target velocity       |         |
| <input type="radio"/>            | ---          | No option    | ---      | 0x6071:00                            | 16 [bit] | INT       | Target torque         |         |
| <input type="radio"/>            | ---          | No option    | ---      | 0x6060:00                            | 8 [bit]  | SINT      | Modes of operation    |         |
| <input type="radio"/>            | Output       | Outputs(Ax1) | Editable | 0x0000:00                            | 8 [bit]  | ---       | ---                   | ---     |
| <input type="radio"/>            | ---          | No option    | ---      | 0x60E0:00                            | 16 [bit] | UINT      | Positive torque limit |         |
| <input type="radio"/>            | ---          | No option    | ---      | 0x60E1:00                            | 16 [bit] | UINT      | Negative torque limit |         |
| <input type="radio"/>            | ---          | No option    | ---      | 0x60B8:00                            | 16 [bit] | UINT      | Touch probe function  |         |

Ax2

| PDO Map                          |              |              |          | ---   |      |           |                |         |
|----------------------------------|--------------|--------------|----------|-------|------|-----------|----------------|---------|
| Selection                        | Input/Output | Name         | Flag     | Index | Size | Data type | PDO entry name | Comment |
| <input checked="" type="radio"/> | ---          | No option    | ---      |       |      |           |                |         |
| <input type="radio"/>            | Output       | Outputs(Ax2) | Editable |       |      |           |                |         |
| <input type="radio"/>            | Output       | Outputs(Ax2) | Editable |       |      |           |                |         |

Ax3

PDO Map

Process Data Size : Input 208 [bit] / 11472 [bit]  
Output 160 [bit] / 11472 [bit]

| Selection                        | Input/Output | Name         | Flag     |
|----------------------------------|--------------|--------------|----------|
| <input checked="" type="radio"/> | ---          | No option    | ---      |
| <input type="radio"/>            | Output       | Outputs(Ax3) | Editable |
| <input type="radio"/>            | Output       | Outputs(Ax3) | Editable |

| Index | Size | Data type | PDO entry name | Comment |
|-------|------|-----------|----------------|---------|
| ---   |      |           |                |         |

Ax4

PDO Map

Process Data Size : Input 208 [bit] / 11472 [bit]  
Output 160 [bit] / 11472 [bit]

| Selection                        | Input/Output | Name         | Flag     |
|----------------------------------|--------------|--------------|----------|
| <input checked="" type="radio"/> | ---          | No option    | ---      |
| <input type="radio"/>            | Output       | Outputs(Ax4) | Editable |
| <input type="radio"/>            | Output       | Outputs(Ax4) | Editable |

| Index | Size | Data type | PDO entry name | Comment |
|-------|------|-----------|----------------|---------|
| ---   |      |           |                |         |

Input (Servo Amplifier to Controller)

Ax1

PDO Map

Process Data Size : Input 208 [bit] / 11472 [bit]  
Output 160 [bit] / 11472 [bit]

| Selection                        | Input/Output | Name        | Flag     |
|----------------------------------|--------------|-------------|----------|
| <input type="radio"/>            | ---          | No option   | ---      |
| <input type="radio"/>            | Input        | Inputs(Ax1) | Editable |
| <input checked="" type="radio"/> | Input        | Inputs(Ax1) | Editable |
| <input type="radio"/>            | ---          | No option   | ---      |
| <input type="radio"/>            | Input        | Inputs(Ax1) | Editable |
| <input type="radio"/>            | ---          | No option   | ---      |
| <input type="radio"/>            | Input        | Inputs(Ax1) | Editable |

PDO entries included in Inputs(Ax1)

| Index     | Size     | Data type | PDO entry name                | Comment |
|-----------|----------|-----------|-------------------------------|---------|
| 0x6041:00 | 16 [bit] | UINT      | Status word                   |         |
| 0x6064:00 | 32 [bit] | DINT      | Position actual value         |         |
| 0x6077:00 | 16 [bit] | INT       | Torque actual value           |         |
| 0x6061:00 | 8 [bit]  | SINT      | Modes of operation display    |         |
| 0x0000:00 | 8 [bit]  | ---       | ---                           | ---     |
| 0x60B9:00 | 16 [bit] | UINT      | Touch probe status            |         |
| 0x60BA:00 | 32 [bit] | DINT      | Touch probe position 1 pos... |         |
| 0x60BC:00 | 32 [bit] | DINT      | Touch probe position 2 pos... |         |
| 0x60FD:00 | 32 [bit] | UDINT     | Digital inputs                |         |
| 0x2100:00 | 16 [bit] | UINT      | Status word 1                 |         |

Ax2

PDO Map

Process Data Size : Input 208 [bit] / 11472 [bit]  
Output 160 [bit] / 11472 [bit]

| Selection                        | Input/Output | Name        | Flag     |
|----------------------------------|--------------|-------------|----------|
| <input checked="" type="radio"/> | ---          | No option   | ---      |
| <input type="radio"/>            | Input        | Inputs(Ax2) | Editable |
| <input type="radio"/>            | Input        | Inputs(Ax2) | Editable |

| Index | Size | Data type | PDO entry name | Comment |
|-------|------|-----------|----------------|---------|
| ---   |      |           |                |         |

Ax3

PDO Map

Process Data Size : Input 208 [bit] / 11472 [bit]  
Output 160 [bit] / 11472 [bit]

| Selection                        | Input/Output | Name        | Flag     |
|----------------------------------|--------------|-------------|----------|
| <input checked="" type="radio"/> | ---          | No option   | ---      |
| <input type="radio"/>            | Input        | Inputs(Ax3) | Editable |
| <input type="radio"/>            | Input        | Inputs(Ax3) | Editable |

| Index | Size | Data type | PDO entry name | Comment |
|-------|------|-----------|----------------|---------|
| ---   |      |           |                |         |

Ax4

PDO Map

Process Data Size : Input 208 [bit] / 11472 [bit]  
Output 160 [bit] / 11472 [bit]

| Selection                        | Input/Output | Name        | Flag     |
|----------------------------------|--------------|-------------|----------|
| <input checked="" type="radio"/> | ---          | No option   | ---      |
| <input type="radio"/>            | Input        | Inputs(Ax4) | Editable |
| <input type="radio"/>            | Input        | Inputs(Ax4) | Editable |

| Index | Size | Data type | PDO entry name | Comment |
|-------|------|-----------|----------------|---------|
| ---   |      |           |                |         |

### 6.1.3. Digital Inputs for Motion Control

Digital inputs such as the home proximity are required to perform motion control.

The following shows the setting items for the Servo Amplifier and connector settings for inputs that are both required to use digital inputs. In this guide, the operation is checked after setting the Servo Amplifier not to detect an error while disconnecting the external inputs.

Use the following settings when you perform 7.3. *SANYO DENKI Servo Amplifier Setup*.

#### General I/O connector settings

| Pin No.                   | Signal name                                    | Description  | Digital inputs assignment |
|---------------------------|--|--|---------------------------|
| 1(CONT1+)/<br>2(CONT1-)   | External Latch Input 1                         | Set the signal function to "Always_Disable".             | Bit16: CONT1              |
| 3(CONT2+)/<br>4(CONT2-)   | External Latch Input 2                         | Set the signal function to "Always_Disable".             | Bit17: CONT2              |
| 5(CONT3+)/<br>6(CONT3-)   | Positive Limit Switch                          | Set the signal function to "Always_Disable".             | Bit18: CONT3              |
| 7(CONT4+)/<br>8(CONT4-)   | Negative Limit Switch                          | Set the signal function to "Always_Disable".             | Bit19: CONT4              |
| 19(CONT5+)/<br>20(CONT5-) | Home Switch                                    | Set the signal function to "Always_Disable".             | Bit20: CONT5              |
| 21(CONT6+)/<br>22(CONT6-) | Immediate Stop Input<br>(Emergency stop (EMR)) | Set the signal function to be enabled while CONT6 is ON. | Bit21: CONT6              |
| 23(CONT7+)/<br>24(CONT7-) | General Input                                  | Set the signal function to "Always_Disable".             | Bit22 : CONT7             |
| 25(CONT8+)/<br>26(CONT8-) | General Input                                  | Set the signal function to "Always_Disable".             | Bit23: CONT8              |


The digital inputs are assigned to the digital inputs object (60FDh) via the general I/O connector on the Servo Amplifier. The relationship between them is described below.

#### Specifications of the digital inputs object

| Index | Sub-index | Name           | Data type | Access | PDO mapping | Saving to EEPROM |
|-------|-----------|----------------|-----------|--------|-------------|------------------|
| 60FDh | 0         | Digital inputs | UDINT     | RO     | Possible    | Not possible     |

Relationship between the digital inputs object and the pin assignment of the general I/O connector

| Digital inputs |                | General I/O connector assignment | Description                 |
|----------------|----------------|----------------------------------|-----------------------------|
| Bit            | Name           |                                  |                             |
| 0              | Negative Limit | —                                | 0:OFF, 1: ON                |
| 1              | Positive Limit | —                                | 0:OFF, 1: ON                |
| 2              | Home           | —                                | 0:OFF, 1: ON                |
| 3              | EMR            | —                                | 0:OFF, 1: ON                |
| 4 to 15        | —              | —                                | Reserved                    |
| 16             | CONT1          | Pins 1 and 2                     | 0:OFF (Open), 1: ON (Close) |
| 17             | CONT2          | Pins 3 and 4                     | 0:OFF (Open), 1: ON (Close) |
| 18             | CONT3          | Pins 5 and 6                     | 0:OFF (Open), 1: ON (Close) |
| 19             | CONT4          | Pins 7 and 8                     | 0:OFF (Open), 1: ON (Close) |
| 20             | CONT5          | Pins 19 and 20                   | 0:OFF (Open), 1: ON (Close) |
| 21             | CONT6          | Pins 21 and 22                   | 0:OFF (Open), 1: ON (Close) |
| 22             | CONT7          | Pins 23 and 24                   | 0:OFF (Open), 1: ON (Close) |
| 23             | CONT8          | Pins 25 and 26                   | 0:OFF (Open), 1: ON (Close) |
| 24 to 31       | —              | —                                | Reserved                    |



The closing brace bracket to the right of the table above indicates the bits that are assigned to the general I/O connector shown on the right (boxed in red).

The red box shown in the table indicates the bits that are used for the digital inputs described in 6.1.5. *Axis Settings for PDO Entries*.

### 6.1.4. Motion Control Axis

The axis number of the Servo Amplifier required for motion control is shown below, which is set in 7.4.3. *Axis Settings for Motion Control*.

| Axis variable name | Axis number | Displayed in Sysmac Studio      |
|--------------------|-------------|---------------------------------|
| MC_Axis000         | 0           | MC_Axis000(0,MC1) <sup>*1</sup> |

\*1 For NJ-series Controllers, the axis name displayed in Sysmac Studio is "MC\_Axis000(0)".

### 6.1.5. Axis Settings for PDO Entries

The axis settings for the Servo Amplifier required for motion control are shown below. For details on each of the objects, refer to 5. *Object Dictionary of the SANMOTION AC SERVO SYSTEMS R ADVANCED MODEL TYPE F With EtherCAT Interface Type H For Rotary Motor, Linear Motor Instruction Manual (M0011195)*.

Use the following settings when you perform 7.4.3. *Axis Settings for Motion Control*.

MC\_Axis000(0,MC1)

| Function Name                                | Device                                 | Process Data  |
|--|--|---|
| - Output (Controller to Device)              |  |   |
| ★ 1. Controlword                             | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 6040h-00.0(Outputs(Ax1)_Control word_6040_00)               |
| ★ 3. Target position                         | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 607Ah-00.0(Outputs(Ax1)_Target position_607A_00)            |
| 5. Target velocity                           | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 60FFh-00.0(Outputs(Ax1)_Target velocity_60FF_00)            |
| 7. Target torque                             | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 6071h-00.0(Outputs(Ax1)_Target torque_6071_00)              |
| 9. Max profile Velocity                      | <Not assigned>                         | <Not assigned>  |
| 11. Modes of operation                       | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 6060h-00.0(Outputs(Ax1)_Modes of operation_6060_00)         |
| 15. Positive torque limit value              | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 60E0h-00.0(Outputs(Ax1)_Positive torque limit_60E0_00)      |
| 16. Negative torque limit value              | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 60E1h-00.0(Outputs(Ax1)_Negative torque limit_60E1_00)      |
| 21. Touch probe function                     | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 60B8h-00.0(Outputs(Ax1)_Touch probe function_60B8_00)       |
| 44. Software Switch of Encoder's Input Slave | <Not assigned>                         | <Not assigned>  |
| - Input (Device to Controller)               |  |   |
| ★ 22. Statusword                             | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 6041h-00.0(Inputs(Ax1)_Status word_6041_00)                 |
| ★ 23. Position actual value                  | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 6064h-00.0(Inputs(Ax1)_Position actual value_6064_00)       |
| 24. Velocity actual value                    | <Not assigned>                         | <Not assigned>  |
| 25. Torque actual value                      | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 6077h-00.0(Inputs(Ax1)_Torque actual value_6077_00)         |
| 27. Modes of operation display               | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 6061h-00.0(Inputs(Ax1)_Modes of operation display_6061_00)  |
| 40. Touch probe status                       | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 60B9h-00.0(Inputs(Ax1)_Touch probe status_60B9_00)          |
| 41. Touch probe pos1 pos value               | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 60BAh-00.0(Inputs(Ax1)_Touch probe position 1_pos1_60BA_00) |
| 42. Touch probe pos2 pos value               | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 60BCh-00.0(Inputs(Ax1)_Touch probe position 2_pos2_60BC_00) |
| 43. Error code                               | <Not assigned>                         | <Not assigned>  |
| 45. Status of Encoder's Input Slave          | <Not assigned>                         | <Not assigned>  |
| 46. Reference Position for csp               | <Not assigned>                         | <Not assigned>  |
| - Digital inputs                             |  |   |
| 28. Positive limit switch                    | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 60FDh-00.18(Inputs(Ax1)_Digital inputs_60FD_00)             |
| 29. Negative limit switch                    | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 60FDh-00.19(Inputs(Ax1)_Digital inputs_60FD_00)             |
| 30. Immediate Stop Input                     | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 60FDh-00.21(Inputs(Ax1)_Digital inputs_60FD_00)             |
| 32. Encoder Phase Z Detection                | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 2100h-00.2(Inputs(Ax1)_Status word_1_2100_00)               |
| 33. Home switch                              | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 60FDh-00.20(Inputs(Ax1)_Digital inputs_60FD_00)             |
| 37. External Latch Input 1                   | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 60FDh-00.16(Inputs(Ax1)_Digital inputs_60FD_00)             |
| 38. External Latch Input 2                   | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 60FDh-00.17(Inputs(Ax1)_Digital inputs_60FD_00)             |

## 6.2. Relationship Between Motion Control via EtherCAT and its Parameter Settings


The following describes the relationship between motion control via EtherCAT and its parameter settings.

This guide describes the parameter settings based on the connection using only Ax1 (axis) of the Servo Amplifier.

Four types of parameters listed below are set in this guide.

| Parameter setting                       | Description   |
|---|---|
| (1)EtherCAT Communications Settings     | EtherCAT communications settings between the Motion Control Device and the Controller |
| (2)PDO Map Settings                     | Data settings for motion control with the Controller                                  |
| (3)Motion Control Setup - Axis Settings | Axis settings (MC_Axis000) for MC instructions  |
| (4)Creating an Operation Check Program  | Program creation and task settings to operate the Motion Control Device               |

Relationship between motion control via EtherCAT and its parameter settings



This figure shows the configuration elements in each file/device related to this guide only.

## 7. EtherCAT Connection Procedure

This section describes the procedures for connecting the Controller and the Servo Amplifier via EtherCAT and for operating the Motion Control Device using an MC instruction for the Controller. The procedures for setting up the Controller and the Servo Amplifier in this guide are based on the factory default settings.

### WARNING

Depending on the Controller status, if you use a Controller that has not been initialized, unexpected operation of the Motion Control Device may occur and result in injury when you turn ON the Controller.

To prevent unexpected operation of the Motion Control Device, make sure to initialize the Controller before connecting the Motion Control Device and the Controller with an Ethernet cable.





#### Additional Information

For information on how to initialize the parameters of a Servo Amplifier, refer to 4.11 *Parameter initialization* of the *MOTOR SETUP SOFTWARE SERVO SYSTEMS Instruction Manual* (M0010842).

### 7.1. Work Flow

Take the following steps to connect the Controller and the Servo Amplifier via EtherCAT and to operate the Motion Control Device using an MC instruction for the Controller.





## 7.2. Preparation for Controller Setup

Prepare to set up the Controller.

### ⚠ WARNING

Depending on the Controller status, if the Controller is being connected to an Ethernet cable, unexpected operation of the Motion Control Device may occur and result in injury when you turn ON the Controller.

Do not connect an Ethernet cable to the Controller when you perform the procedures described here.




### 7.2.1. Starting Sysmac Studio and Going Online

Start Sysmac Studio and go online with the Controller.


|   |  |  |
|---|--|--|
| 1 | Make sure that Controller is powered OFF.  |  |
| 2 | Connect Personal computer and PORT1 EtherNet/IP on Controller with a LAN cable. Check that an Ethernet cable is <b>disconnected</b> from PORT3 EtherCAT on Controller. |  |
| 3 | Turn ON Controller.  |  |
| 4 | Start Sysmac Studio.<br><br>*If the User Account Control Dialog Box is displayed at start, make a selection to start Sysmac Studio.                                    |  |
| 5 | Sysmac Studio is started. Click <b>Connect to Device</b> .   |  |

6 The Connect to Device Dialog Box is displayed. Select **Controller** from the pull-down list in the *Device* Field and *Direct connection via Ethernet* in the *Connection type* Field. Uncheck both *Transfer from Device* and *Display the Troubleshooting Dialog Box* in the *Operation after Connection* Field.




Click **Connect**.

7 A confirmation dialog box is displayed. Check the contents and click **OK**.




\*The contents of the dialog box vary depending on the status of Controller. Check the contents and click on an appropriate button to proceed with the processing.

8 The dialog box on the right is displayed. Check the contents and click **OK**.



9 The Auto Connect Project Dialog Box is displayed online. When an online connection is established, a yellow line is displayed under the toolbar.



The following panes are displayed in the window.

- Left: Multiview Explorer
- Top right: Toolbox
- Bottom right: Controller Status Pane
- Top middle: Edit Pane

The following tabs are displayed in the bottom middle of the window.

- Output Tab Page
- Build Tab Page





### Additional Information




For more information on online connections, refer to *Section 6. Online Connections to a Controller* of the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504).

10

Select **Mode – PROGRAM Mode** from the Controller Menu.

The dialog box on the right is displayed. Confirm that there is no problem, and click **Yes**.

The operating mode of Controller displayed in the Controller Status Pane changes to PROGRAM mode.



### 7.2.2. Initializing the Controller

Initialize the data in the Controller.






#### Precautions for Correct Use

All memory will be cleared after initialization.

If there is necessary data in the Controller, save the data.




Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504) for information on operating Sysmac Studio.





|   |   |
|---|---|
| <p>1 Select <b>Clear All Memory</b> from the Controller Menu.</p> | <p>The screenshot shows the 'Controller' menu in Sysmac Studio. The menu items are: Communications Setup..., Change Device, Online (Ctrl+W), Offline (Ctrl+Shift+W), Synchronize... (Ctrl+M), Transfer..., Mode, Monitor, Stop Monitoring, Set/Reset, Forced Refreshing, MC Test Run, MC Monitor Table..., CNC Coordinate System Monitor Table, SD Memory Card..., Controller Clock..., Release Access Right..., Update CPU Unit Name..., Security, <b>Clear All Memory...</b> (highlighted in blue), and Reset Controller...</p> |
|---|---|

|  |  |
|--|--|
| <p>2 The Clear All Memory Dialog Box is displayed.<br/>Click <b>OK</b>.</p>                |    |
| <p>3 A confirmation dialog box is displayed. Check the contents and click <b>Yes</b>.</p>  |   |
| <p>4 The dialog box on the right is displayed. Check the contents and click <b>OK</b>.</p> |  |

7.2.3. Installing the ESI File

Install the ESI file for the Servo Amplifier in Sysmac Studio.

|  |   |
|--|---|
| <p>1 Double-click <b>EtherCAT</b> under <b>Configurations and Setup</b> in the Multiview Explorer.</p> |   |
| <p>2 The EtherCAT Tab Page is displayed in the Edit Pane.</p>  |   |
| <p>3 Right-click <b>Master</b> and select <b>Display ESI Library</b>.</p>                              |  |

|  |  |
|--|--|
| <p>4 The ESI Library Dialog Box is displayed.<br/>Click the <b>this folder</b> link.</p> <p>When the Explorer is started, click <b>Close</b> to close the dialog box.</p>  |    |
| <p>5 The Explorer is started, and a linked folder is opened, allowing you to install the ESI file.<br/>Copy the prepared <i>P0010959C01.xml</i> to the linked folder.</p> <p>*If an access permission confirmation dialog box is displayed when copying the ESI file, permit access to the folder to continue.</p> |    |
| <p>6 Select <b>Exit</b> from the File Menu to exit Sysmac Studio.</p> <p>*You need to restart Sysmac Studio after installing the ESI file.</p> <p>A dialog box is displayed confirming whether to save the project.<br/>Click <b>No</b> if you do not need to save.</p>  | <br> |
| <p>7 Restart Sysmac Studio.<br/>(Perform steps 4 to 9 of 7.2.1. <i>Starting Sysmac Studio and Going Online.</i>)</p>   |  |


8 In the same way as steps 1 to 3, display the ESI Library Dialog Box.

Check that P0010959C01 is displayed. Click the + Button to the left of it.

A list of devices that can be used for the ESI file is displayed. Check that the device used is listed in there.

Check that there are no exclamation marks (errors) displayed.

Click **Close**.



"SanyoDenki RF2 EtherCAT Rev:0x00000000 (RF2-EtherCAT (P0010959C01:25.Jan,2017))" is used in this guide.




**Precautions for Correct Use**

If an exclamation mark (error) is displayed for the ESI file, check the name of the ESI file and obtain the ESI file with a correct name.

If an exclamation mark (error) is displayed even when the name of the ESI file is correct, the file may be corrupted. In that case, contact the device manufacturer.

9 Select **Offline** from the Controller Menu.




The yellow line under the toolbar disappears.



10 Turn OFF Controller.

11 Connect an Ethernet cable to PORT3 EtherCAT on Controller.

\*Make sure that the power supply to Controller remains OFF.



### 7.3. SANYO DENKI Servo Amplifier Setup

Set up the SANYO DENKI Servo Amplifier.



#### Additional Information

For details on the external I/O wiring and parameter settings for Servo Amplifiers, refer to the *SANMOTION AC SERVO SYSTEMS R ADVANCED MODEL TYPE F With EtherCAT Interface Type H For Rotary Motor, Linear Motor Instruction Manual (M0011195)*.



#### Additional Information

The scope of this guide covers the "connection check of the Motion Control Device connected via EtherCAT using the MC\_Power instruction"; hence, a regenerative resistor is not used. If you connect a regenerative resistor, refer to *4.1 Control power supply, Regeneration resistance, and Wiring protective ground* and *12.2 Capacity Selection of Regenerative Resistor* of the *SANMOTION AC SERVO SYSTEMS R ADVANCED MODEL TYPE F with EtherCAT Interface Type H For Rotary Motor, Linear Motor Instruction Manual (M0011195)*.

#### 7.3.1. Hardware Settings

Set the hardware switches on the Servo Amplifier and connect the cables.

### Caution





The scope of this guide covers the "connection check of the Motion Control Device connected via EtherCAT using the MC\_Power instruction"; accordingly, the positive and negative limit switch functions are always disabled. The external I/O to turn ON the positive and negative limit switches is not connected to the general I/O connector in this guide. Make appropriate settings for your device when you actually design a system.



#### Precautions for Correct Use


Make sure that the power supplies are OFF when you set up. If either of them is ON, the settings described in the following steps and subsequent procedures may not be applicable.

- 1 Make sure that Control power supply and Main circuit power supply are OFF.

|   |   |
|---|---|
| <p>2 Check the positions of the hardware switches and connectors on Servo Amplifier by referring to the figure on the right.</p>  |  <ul style="list-style-type: none"> <li>Power input connector for control and main circuit (CNA)</li> <li>Regenerative resistor connector</li> <li>General I/O connector (I/O)</li> <li>Connector for encoder signal (EN1, EN2, EN3 and EN4)</li> <li>Rotary switch for station alias address ADDR (HI, LOW)</li> <li>Connector for setup software (PC)</li> <li>OUT connector for EtherCAT communications</li> <li>IN connector for EtherCAT communications</li> <li>Servo motor connector (MOT1, MOT2, MOT3 and MOT4)</li> </ul> |
| <p>3 Set Rotary switch for station alias address ADDR (HI, LOW) as follows:<br/>         HI: 0<br/>         LOW: 1</p> <p>*The node address is set to 1.</p>  |    |
| <p>4 Connect the Ethernet cable to IN connector for EtherCAT communications.</p> <p>*Connect IN connector for EtherCAT communications and PORT3 EtherCAT on Controller with the Ethernet cable.</p> |   |
| <p>5 Connect the COM port on Personal computer and Connector for setup software (PC) with a PC communication cable.</p>   |   |


6 Connect an Encoder cable for Servo Motor to Connector for encoder signal (EN1).

\*For details on Connector for encoder signal, refer to 4.2 *Wiring of Motor Encoder* of the *SANMOTION AC SERVO SYSTEMS R ADVANCED MODEL TYPE F With EtherCAT Interface Type H For Rotary Motor, Linear Motor Instruction Manual* (M0011195).



7 Connect a Power cable for Servo Motor to Servo motor connector (MOT1).


\*For details on Servo motor connector, refer to 4.1 *Control power supply, Regeneration resistance, and Wiring protective ground* of the *SANMOTION AC SERVO SYSTEMS R ADVANCED MODEL TYPE F With EtherCAT Interface Type H For Rotary Motor, Linear Motor Instruction Manual* (M0011195).



- 8 Connect Control and Main circuit power supplies to Power input connector for control and main circuit (CNA).

\*For details on power supply specifications, refer to 2 *Specifications of the SANMOTION AC SERVO SYSTEMS R ADVANCED MODEL TYPE F With EtherCAT Interface Type H For Rotary Motor, Linear Motor Instruction Manual* (M0011195).

\*For information on power supply wiring, refer to 4.1 *Control power supply, Regeneration resistance, and Wiring protective ground of the SANMOTION AC SERVO SYSTEMS R ADVANCED MODEL TYPE F With EtherCAT Interface Type H For Rotary Motor, Linear Motor Instruction Manual* (M0011195).



### 7.3.2. Parameter Settings

Set parameters for the Servo Amplifier.

The SANMOTION Motor Setup software is used to set parameters.

Install the software on your personal computer beforehand.

## Caution

The scope of this guide covers the "connection check of the Motion Control Device connected via EtherCAT using the MC\_Power instruction"; accordingly, the positive and negative limit switch functions are always disabled.

The input signal assignment of the positive and negative limit switches is set to "Always\_Disable" to disable their functions. No error therefore occurs even without connecting the positive and negative limit switches.

Make appropriate settings for your device when you actually design a system.



### Precautions for Correct Use


For information on power-on sequence of the control and main circuit power supplies to a Servo Amplifier, refer to *6.5 Operation Sequence* of the *SANMOTION AC SERVO SYSTEMS R ADVANCED MODEL TYPE F With EtherCAT Interface Type H For Rotary Motor, Linear Motor Instruction Manual (M0011195)*.



### Additional Information

For information on installing SANMOTION Motor Setup, refer to *SANYO DENKI Global Site* or contact SANYO DENKI CO., LTD.


- 1 Turn ON Control power supply and Main circuit power supply.
- 2 Start SANMOTION Motor Setup.



3 SANMOTION Motor Setup is started, and the main window is displayed.

The following parts are displayed in the window.

- Left: Side menu
- Middle right: Information on axis being selected
- Bottom right: Functional panel





4 The Communication Setting Window is displayed after SANMOTION Motor Setup is started.

From the pull-down list of COM Port, select the port number to be used.


Click **COM Auto allocate**.

\*If there is more than one serial port on your personal computer, display Windows Device Manager and select the same port number as the communications port (displayed under Ports (COM & LPT)) to which Servo Amplifier is connected (example: COM1).


\*To open Windows Device Manager, right-click the start button, and click to select **Device Manager** from the list.




5 A confirmation dialog box is displayed. Confirm that there is no problem, and click **OK**.



The Scanning COM port amplifier Dialog Box is displayed.




A confirmation dialog box is displayed. Check the contents and click **OK**.



6 Check that the axis numbers from 1 to 4 are displayed in the *Axis* Column in the Communication Setting Window.


Click **Connect all**.




- 7 Check that the green light  (to the left of the axis numbers 1 to 4) comes ON.

Click **Close**.

\*The Communication Setting Window is closed.



- 8 Select **Option settings** from the Option Menu of the main window.





- 9 The Option settings Window is displayed.


Select **Advanced** from the pull-down list of Operation Level.

Click **OK**.


\*All the parameters of Servo Amplifier can be edited when setting the operation level to Advanced.



10 The main window is displayed. Select **Parameter** from the Side menu.



11 The Parameter menu window is displayed in the Functional panel. Select **Axis 1** in the Axis-selector and click **Each Group**.



12 The Setting of each group Parameter (Axis 1) Window is displayed. The system parameter group is displayed in the List of parameters.

Motor parameters

Amplifier/motor model No.

| ID | Name             | Present Setting  | Unit            | Input Value | Minimum | Maximum | Standard          |
|----|------------------|--|-----------------|-------------|---------|---------|-------------------|
| 00 | (02FD-1)MPWR     | Main Circuit Power Input Type                          | (02)DC          | -           | -       | -       | (02)DC            |
| 01 | (16)KND          | Regenerative Resistor Selection                        | (01)Built-in    | -           | -       | -       | (02)Not_connected |
| 02 | (02)F3-ENCOD     | Combined sensor resolution                             | FFFF            | -           | 0000    | FFFF    | FFFF              |
| 03 | (02)F3-2-ENTYPE  | Combined sensor type                                   | FFFF            | -           | 0000    | FFFF    | FFFF              |
| 04 | (02)F3-1-POINTS  | Position Control Selection                             | (00)Standard    | -           | -       | -       | (00)Standard      |
| 05 | (02)F3-2-PLURDCE | Position Loop Control: Position Loop Encoder Selection | (00)Motor_Enc   | -           | -       | -       | (00)Motor_Enc     |
| 06 | (02)F3-3-EXFEN   | External Pulse Encoder Resolution                      | 2048            | P/R         | 500     | 9999    | 2000              |
| 07 | (02)F3-4-RESSEL  | Serial Encoder Function Selection                      | (00)PA_S_2-5M   | -           | -       | -       | (00)PA_S_2-5M     |
| 08 | (02)F3-5-RESRES  | Serial Encoder Resolution                              | (01)8192_FMT    | -           | -       | -       | (06)110172_FMT    |
| 09 | (02)F3-6-PASEL   | Backup Type Absolute (Encoder Function) Selection      | (01)Incremental | -           | -       | -       | (00)Absolute_S    |
| 10 | (02)F3-7-INITTRM | Waiting Time for Initial Process                       | (00)Disabled    | -           | -       | -       | (00)Disabled      |
| 11 | (02)F3-8-MCINT   | Module initialization warning detection setting        | (01)Enabled     | 0           | 0       | 65535   | (01)Enabled       |
| 12 | (02)F3-9-ASV     | Enable sea setting                                     | (01)Enabled     | -           | -       | -       | (01)Enabled       |
| 13 | (02)F3-10-ASV    | Main Power Supply Voltage                              | (03)48V         | -           | -       | -       | (03)48V           |

Group

Explanation tab

Log tab

List of parameters

13 Edit the value of Combined motor code listed in the system parameter group, by following the steps below. Select *Combined motor code* and click **Edit**.

| System |                   |  |                   |      |             |
|--------|-------------------|--|-------------------|------|-------------|
| ID     | Symbol            | Name   | Present Setting   | Unit | Input Value |
| * 00   | 0x20FD-1:MPWR...  | Main Circuit Power Input Type                          | 02:DC             | -    |             |
| * 01   | RGKIND            | Regenerative Resistor Selection                        | 01:Built-in_R     | -    |             |
| * 02   | 0x20FE:MOCODE     | Combined motor code                                    | FFFF              | -    |             |
| * 03   | 0x20FF-1:ENCODE   | Combined sensor resolution setting                     | FFFF              | -    |             |
| * 04   | 0x20FF-2:ENTYPE   | Combined sensor type                                   | FFFF              | -    |             |
| * 07   | 0x20F3-1:PCNTS... | Position Control Selection                             | 00:Standard       | -    |             |
| * 08   | 0x20F3-2:PLMODE   | Position Loop Control, Position Loop Encoder Selection | 00:Motor_Enc      | -    |             |
| * 09   | 0x20FF-3:EXPEN... | External Pulse Encoder Resolution                      | 2000              | P/R  |             |
| * 10   | SERENSEL          | Serial Encoder Function Selection                      | 00:PA_S_2.5M      | -    |             |
| * 11   | SERENRES          | Serial Encoder Resolution                              | 02:8192_FMT       | -    |             |
| * 12   | PASEL             | Backup Type Absolute Encoder Function Selection        | 01:Incremental... | -    |             |
| * 14   | INTTIM            | Waiting Time for Initial Process                       | 00:Disabled       | -    |             |
| * 18   | 0x20FC:MDLINT...  | Modulo initialization warning detection setting        | 0                 |      |             |
| * 19   | AxisEnable        | Enable axis setting                                    | 01:Enabled        |      |             |
| * 1A   | 0x20FD-4:MPWR...  | Main Power Supply Voltage                              | 03:48V            |      |             |

**Edit(E)...** When the data of the head \* mark is changed, it becomes effective after power supply re-input.

14 The Parameter Edit (Axis 1) Window is displayed. Enter the combined motor code (example: 049B) that is used for Servo Motor specified in 5.2. *Device Configuration*, in the *Input Value* Field. Click **OK**.

Parameter Edit(Axis1)

Amplifier/Motor Model: RF2K24A0HA5 R2GA02D20F

Group/ID: System-02 Symbol: 0x20FE:MOCODE

Name: Combined motor code

Present Setting Value: FFFF Standard Setting Value: FFFF

Input Value:  (0000 - FFFF)

Explanation: Sets the code of the drive motor.  
 \* Initialized by the motor code set as EEPROM at power ON state. When the motor code has a setting parameter different from the EEPROM value, the function will be enabled with control source re-closing. After the new value is set in EEPROM, alarm "DE: parameter change completed" occurs, then re-close control source.

\*For more information on the combined motor code, refer to *0x20FE : Combination Motor Code* in 5.6. *Manufacturer Specific Area of the SANMOTION AC SERVO SYSTEMS R ADVANCED MODEL TYPE F With EtherCAT Interface Type H For Rotary Motor, Linear Motor Instruction Manual* (M0011195).

15 Check that the combined motor code (049B) set in step 14 is displayed in the *Input Value* Column.

| System |                  |                                    |                 |      |             |
|--------|------------------|------------------------------------|-----------------|------|-------------|
| ID     | Symbol           | Name                               | Present Setting | Unit | Input Value |
| * 00   | 0x20FD-1:MPWR... | Main Circuit Power Input Type      | 02:DC           | -    |             |
| * 01   | RGKIND           | Regenerative Resistor Selection    | 01:Built-in_R   | -    |             |
| * 02   | 0x20FE:MOCODE    | Combined motor code                | FFFF            | -    | 049B        |
| * 03   | 0x20FF-1:ENCODE  | Combined sensor resolution setting | FFFF            | -    |             |
| * 04   | 0x20FF-2:ENTYPE  | Combined sensor type               | FFFF            | -    |             |

16 In the same way as steps 13 to 15, set the following parameters.

- Combined sensor resolution setting: 0002
- Combined sensor type: 0101
- Enable axis setting: **01:Enabled**

\*For information on the combined sensor resolution setting and combined sensor type, refer to 0x20FF : Combination Encoder Selection in 5.6. Manufacturer Specific Area of the SANMOTION AC SERVO SYSTEMS R ADVANCED MODEL TYPE F With EtherCAT Interface Type H For Rotary Motor, Linear Motor Instruction Manual (M0011195).

| System |                   |  |                   |      |             |
|--------|-------------------|--|-------------------|------|-------------|
| ID     | Symbol            | Name   | Present Setting   | Unit | Input Value |
| 00     | 0x20FD-1:MPWR...  | Main Circuit Power Input Type                          | 02:DC             | -    |             |
| 01     | RGKIND            | Regenerative Resistor Selection                        | 01:Built-in_R     | -    |             |
| 02     | 0x20FE:MOCODE     | Combined motor code                                    | FFFF              | -    | 049B        |
| 03     | 0x20FF-1:ENCODE   | Combined sensor resolution setting                     | FFFF              | -    | 0002        |
| 04     | 0x20FF-2:ENTYPE   | Combined sensor type                                   | FFFF              | -    | 0101        |
| 07     | 0x20F3-1:PCNTS... | Position Control Selection                             | 00:Standard       | -    |             |
| 08     | 0x20F3-2:PLMODE   | Position Loop Control, Position Loop Encoder Selection | 00:Motor_Enc      | -    |             |
| 09     | 0x20FF-3:EXPEN... | External Pulse Encoder Resolution                      | 2000              | P/R  |             |
| 10     | SERENSEL          | Serial Encoder Function Selection                      | 00:PA_S_25M       | -    |             |
| 11     | SERENRES          | Serial Encoder Resolution                              | 02:8192_FMT       | -    |             |
| 12     | PASEL             | Backup Type Absolute Encoder Function Selection        | 01:Incremental... | -    |             |
| 14     | INTTIM            | Waiting Time for Initial Process                       | 00:Disabled       | -    |             |
| 18     | 0x20FC:MDLINT...  | Modulo initialization warning detection setting        | 0                 | -    |             |
| 19     | AxisEnable        | Enable axis setting                                    | 01:Enabled        | -    |             |
| 1A     | 0x20FD-4:MPWR...  | Main Power Supply Voltage                              | 03:48V            | -    |             |

17 Click **Group 7 [Communication /Display]** in the Group.

Group 7 [Communication/Display] is displayed in the List of parameters.

Check that the following parameter value is set in the Present Setting Value Column.

- SM2 Sync mode: 0002 (SYNC0 Event Synchronization (Synchronized with SYNC0 Hardware Signal))

\*If the present setting value is different, change the value in the same way as steps 13 to 15.

| Motor Parameter                                  |                  |                                  |                 |      |  |
|--|------------------|----------------------------------|-----------------|------|--|
| ID   | Symbol           | Name                             | Present Setting | Unit |  |
| Amplifier/Motor Model   RF2K24A0HA5   R2GA02D20F |                  |                                  |                 |      |  |
| <b>Group 7 [Communication/Display]</b>           |                  |                                  |                 |      |  |
| 00   | 0x6060:OPMODE    | Modes of operation               | 08:CSP          | -    |  |
| 01   | 0x2000:CWORD1    | Control word 1                   | 0000-0000.000.  | -    |  |
| 02   | 0x1C32-1:SM2TYP  | SM2 Sync mode                    | 0002            | -    |  |
| 03   | 0x1C32-2:SYCLE   | SM2 Sync cycle time              | 4000000         | nsec |  |
| 04   | 0x1C33-1:SM3TYP  | SM3 Sync mode                    | 0002            | -    |  |
| 05   | 0x20FD-3:COMB... | Serial Communication Baud Rate   | 05:38400bps     | -    |  |
| 06   | 0x20F4:SLPDRY    | Servo loop delay time            | 239             | -    |  |
| 07   | 0x20F7:SpFuncSw  | Special Function Select Settings | 0               | -    |  |
| 08   | 0x20FA-1:EXALIAS | Extend station alias             | 00              | *16  |  |
| 09   | 0x20FA-2:ALIASL  | Extend unit alias                | 00              | -    |  |
| 0A   | MONDISP          | Monitor Display Selection        | 00:STATUS       | -    |  |
| 0B   | COMAXIS          | Serial Communication Axis Number | 01:#1           | -    |  |
| 0C   | 0x2035-7:MSTE... | Assist target axis address       | 0001            | -    |  |

18 Click **Group 9 [Function/ Output Select]** in the Group. Group 9 [Function/Output Select] is displayed in the List of parameters. Set the following parameters in the same way as steps 13 to 15.

- Positive Limit Switch Function: **00:Always\_Disable**
- Negative Limit Switch Function: **00:Always\_Disable**
- Emergency Stop Function: **0C:CONT6\_ON**

| ID | Symbol           | Name   | Present Setting Value | Unit | Input Value |
|----|------------------|--|-----------------------|------|-------------|
| 00 | 0x20F8-1:PLMSW   | Positive Limit Switch Function                 | 00:Always_Disable     | -    | -           |
| 01 | 0x20F8-2:NLMSW   | Negative Limit Switch Function                 | 00:Always_Disable     | -    | -           |
| 02 | 0x20F8-3:EXT-E   | External Trip Input Function                   | 00:Always_Disable     | -    | -           |
| 03 | 0x20E8-4:DISCH   | Main Power Disable Function                    | 00:Always_Disable     | -    | -           |
| 0C | 0x20F8-6:EMR     | Emergency Stop Function                        | 00:Always_Disable     | -    | CONT6_ON    |
| 05 | 0x20F0-1:ACTOT   | Limit Switch Action                            | 06:CMDACK_VCLM=0      | -    | -           |
| 06 | 0x20F0-2:EDGEPE  | Positioning Methods                            | 00:Pulse_Interval     | -    | -           |
| 07 | 0x20F0-3:PDEV    | In Position Signal/ Position Deviation Monitor | 00:After_Filter       | -    | -           |
| 08 | 0x20F0-4:VCMPIUS | Speed Matching Line Selection                  | 00:min-1              | -    | -           |
| 09 | 0x20F0-5:CLR     | Deviation Clear Selection                      | 00:Type1              | -    | -           |
| 0A | 0x20F9-1:OUI1    | General Purpose Output 1 Selection             | 42:FOI11_DN           | -    | -           |
| 0B | 0x20F9-2:OUI2    | General Purpose Output 2 Selection             | 44:FOI12_DN           | -    | -           |
| 10 | 0x2023-1:MON1    | Analog Monitor Select Output 1                 | 05:VMON1_Inv/min-1    | -    | -           |
| 11 | 0x2023-2:MON2    | Analog Monitor Select Output 2                 | 02:TCMON2_2V/TR       | -    | -           |
| 12 | 0x2023-3:MONPOL  | Analog Monitor Output Polarity                 | 00:MON1+_MON2+        | -    | -           |


19 Click **Group C [Encoder/ Alarm]** in the Group. Group C [Encoder/Alarm] is displayed in the List of parameters. Check that the following parameter value is set in the *Present Setting Value* Column.

- Flag for the axis between the interlock mask: **10:Disable**

| ID | Symbol            | Name   | Present Setting Value | Input Value |
|----|-------------------|--|-----------------------|-------------|
| 00 | 0x20F1-1:ECLRF    | Encoder Clear Function Selection             | 00:Status_MultiTurn   | -           |
| 02 | 0x20F1-3:EX-EN... | External Pulse Encoder Digital Filter        | 01:220nsec            | -           |
| 03 | 0x20F1-4:EX-EN... | External Pulse Encoder Polarity Selection    | 00:Type1              | -           |
| 04 | 0x20F2-1:MPESSEL  | Main Power Error Selection                   | 01:MPPE_ENA           | -           |
| 05 | 0x20F2-2:VCALM    | Velocity Control Alarm (ALM_C2) Detection    | 00:Disabled           | -           |
| 06 | 0x20F2-3:VFBALM   | Velocity Feedback Alarm (ALM_C3) Detecti...  | 01:Enabled            | -           |
| 07 | 0x20F2-4:CRCSSET  | Frame error filter                           | 0                     | -           |
| 08 | 0x20F2-5:COTOUT   | Communication timeout filter                 | 0                     | -           |
| 09 | 0x201D:OVFSET     | Position Command Error 1 Level               | 4284967295            | -           |
| 0B | SIFMSK            | Flag for the axis between the interlock mask | 10:Disable            | -           |

\*If the present setting value is different, change the value in the same way as steps 13 to 15.

20 Select **Write in amplifier** from the Amplifier Menu.



21 Check that the parameter values changed in steps 13 to 19 are reflected.

Click **System** in the Group.

The system parameter group is displayed. Check that the following parameter values are set in the *Present Setting Value* Column.

- Combined motor code: 049B
- Combined sensor resolution setting: 0002
- Combined sensor type: 0101

\*The values in the *Input Value* Column will be blank once the parameter settings are reflected.

| ID | Symbol            | Name  | Present Setting Value | Unit |
|----|-------------------|---|-----------------------|------|
| 00 | 0x20FD-1.MPWR...  | Main Circuit Power Input Type                   | 02:DC                 | -    |
| 01 | RGKIND            | Regenerative Resistor Selection                 | 01:Built_in_R         | -    |
| 02 | 0x20FE.MOCODE     | Combined motor code                             | 049B                  | -    |
| 03 | 0x20FF-1.ENCODE   | Combined sensor resolution setting              | 0002                  | -    |
| 04 | 0x20FF-2.ENTYPE   | Combined sensor type                            | 0101                  | -    |
| 07 | 0x20F3-1.PCNTS... | Position Control Selection                      | 00:Standard           | -    |
| 08 | 0x20F3-2.PLIMODE  | Position Loop Control, Position Loop Encod...   | 00:Motor_Enc          | -    |
| 09 | 0x20FF-3.EXPEN... | External Pulse Encoder Resolution               | 2000                  | P/R  |
| 10 | SERENSEL          | Serial Encoder Function Selection               | 00:PA_S_2.5M          | -    |
| 11 | SERENRES          | Serial Encoder Resolution                       | 02:8192_FMT           | -    |
| 12 | PASEL             | Backup Type Absolute Encoder Function S...      | 01:Incremental_System | -    |
| 14 | INTTIM            | Waiting Time for Initial Process                | 00:Disabled           | -    |
| 18 | 0x20FC.MDLUNT...  | Modulo initialization warning detection setting | 0                     | -    |
| 19 | AxisEnable        | Enable axis setting                             | 01:Enabled            | -    |
| 1A | 0x20FD-4.MPWR...  | Main Power Supply Voltage                       | 03:48V                | -    |

22 Click **Group 9 [Function/ Output Select]** in the Group.

Group 9 [Function/Output Select] is displayed in the List of parameters.

Check that the following parameter value is set in the *Present Setting Value* Column.


- Emergency Stop Function: 00:CONT6\_ON

\*If there are some more parameters you have changed, check that all the changed parameter values are reflected in the *Present Setting Value* Column.


| ID | Symbol            | Name   | Present Setting Value |
|----|-------------------|--|-----------------------|
| 00 | 0x20F8-1.PLIMSW   | Positive Limit Switch Function                 | 00:Always_Disable     |
| 01 | 0x20F8-2.NLIMSW   | Negative Limit Switch Function                 | 00:Always_Disable     |
| 02 | 0x20F8-3.EXT-E    | External Trip Input Function                   | 00:Always_Disable     |
| 03 | 0x20F8-4.DISCH... | Main Power Discharge Function                  | 00:Always_Disable     |
| 04 | 0x20F8-5.EMR      | Emergency Stop Function                        | 00:CONT3_ON           |
| 05 | 0x20F0-1.ACTOT    | Limit Switch Action                            | 06:CMDACK_VCLM=0      |
| 06 | 0x20F0-2.EDGE...  | Positioning Methods                            | 00:Pulse_Interval     |
| 07 | 0x20F0-3.PDEV...  | In-Position Signal/ Position Deviation Monitor | 00:After_Filter       |
| 08 | 0x20F0-4.VCMPUS   | Speed Matching Unit Selection                  | 00:min-1              |
| 09 | 0x20F0-5.CLR      | Deviation Clear Selection                      | 00:Type1              |
| 0A | 0x20F9-1.OUT1     | General Purpose Output 1 Selection             | 42:FOUT1_ON           |
| 0B | 0x20F9-2.OUT2     | General Purpose Output 2 Selection             | 44:FOUT2_ON           |
| 10 | 0x2023-1.MON1     | Analog Monitor Select Output 1                 | 05:VMON_2mV/min-1     |
| 11 | 0x2023-2.MON2     | Analog Monitor Select Output 2                 | 02:TCMON_2V/TR        |
| 12 | 0x2023-3.MONPOL   | Analog Monitor Output Polarity                 | 00:MON1+_MON2+        |

23 Select **Close** from the File Menu.


\*The Setting of each group Parameter (Axis 1) Window is closed.



24 Set the unused axes (Ax2 to Ax4) by following the steps below.  
 Select Axis 2 in the Axis-selector and click **Each Group** in the Parameter menu window.



25 The Setting of each group Parameter (Axis 2) Window is displayed.  
 The system parameter group is displayed in the List of parameters.



26 Set the following parameter in the same way as steps 13 to 15.  
 • Enable axis setting:  
**00:Disabled**


| System |               |                                  |                    |      |             |  |
|--------|---------------|----------------------------------|--------------------|------|-------------|--|
| ID     | Symbol        | Name                             | Present Setting    | Unit | Input Value |  |
| * 00   | 0x20FD-1:...  | Main Circuit Power Input Type    | 02:DC              | -    |             |  |
| * 02   | 0x20FE:M...   | Combined motor code              | FFFF               | -    |             |  |
| * 03   | 0x20FF-1:E... | Combined sensor resolution ...   | FFFF               | -    |             |  |
| * 04   | 0x20FF-2:E... | Combined sensor type             | FFFF               | -    |             |  |
| * 07   | 0x20F3-1:P... | Position Control Selection       | 00:Standard        | -    |             |  |
| * 08   | 0x20F3-2:P... | Position Loop Control, Positi... | 00:Motor_Enc       | -    |             |  |
| * 09   | 0x20FF-3:E... | External Pulse Encoder Res...    | 2000               | P/R  |             |  |
| * 10   | SERENSEL      | Serial Encoder Function Sel...   | 00:PA_S_2.5M       | -    |             |  |
| * 11   | SERENRES      | Serial Encoder Resolution        | 02:8192_FMT        | -    |             |  |
| * 12   | PASEL         | Backup Type Absolute Enc...      | 01:Incremental_... | -    |             |  |
| * 14   | INTTIM        | Waiting Time for Initial Proc... | 00:Disabled        | -    |             |  |
| * 18   | 0x20FC:M...   | Modulo initialization warning... | 0                  |      |             |  |
| * 19   | AxisEnable    | Enable axis setting              | 01:Enabled         |      | 00:Disabled |  |
| * 1A   | 0x20FD-4:...  | Main Power Supply Voltage        | 03:48V             |      |             |  |

27 Click **Group C [Encoder/Alarm]** in the Group. Group C [Encoder/Alarm] is displayed in the List of parameters. Check that the following parameter is set in the *Present Setting Value* Column.

- Flag for the axis between the interlock mask: 00:Enable

| ID | Symbol        | Name   | Present Setting    | Unit | Input Value |
|----|---------------|--|--------------------|------|-------------|
| 00 | 0x20F1-1.E... | Encoder Clear Function Selection             | 00:Status_Multi... | -    |             |
| 02 | 0x20F1-3.E... | External Pulse Encoder Digital Filter        | 01:220nsec         | -    |             |
| 03 | 0x20F1-4.E... | External Pulse Encoder Polarity Selection    | 00:Type1           | -    |             |
| 04 | 0x20F2-1:...  | Main Power Error Selection                   | 01:MPE_ENA         | -    |             |
| 05 | 0x20F2-2.V... | Velocity Control Alarm (ALM_C2) Detection    | 00:Disabled        | -    |             |
| 06 | 0x20F2-3.V... | Velocity Feedback Alarm (ALM_C3) Detection   | 01:Enabled         | -    |             |
| 07 | 0x20F2-4.C... | Frame error filter                           |                    | 0    |             |
| 08 | 0x20F2-5.C... | Communication timeout filter                 |                    | 0    |             |
| 09 | 0x201D.OV...  | Position Command Error 1 Level               | 4294967295         | pps  |             |
| 0B | SIFMSK        | Flag for the axis between the interlock mask | 10:Disable         |      | 00:Enable   |

28 Select **Write in amplifier** from the Amplifier Menu.



29 Check that the parameter values changed in steps 25 to 28 are reflected. Click **System** in the Group. The system parameter group is displayed. Check that the following parameter value is set in the *Present Setting Value* Column.


- Enable axis setting: 00:Disabled

| ID | Symbol        | Name  | Present Setting    | Unit |
|----|---------------|---|--------------------|------|
| 00 | 0x20FD-1:...  | Main Circuit Power Input Type                   | 02:DC              | -    |
| 02 | 0x20FE:M...   | Combined motor code                             | FFFF               | -    |
| 03 | 0x20FF-1.E... | Combined sensor resolution setting              | FFFF               | -    |
| 04 | 0x20FF-2.E... | Combined sensor type                            | FFFF               | -    |
| 07 | 0x20F3-1:P... | Position Control Selection                      | 00:Standard        | -    |
| 08 | 0x20F3-2.P... | Position Loop Control, Position Loop Encoder... | 00:Motor_Enc       | -    |
| 09 | 0x20FF-3.E... | External Pulse Encoder Resolution               | 2000               | P/R  |
| 10 | SERENSEL      | Serial Encoder Function Selection               | 00:PA_S_2.5M       | -    |
| 11 | SERENRES      | Serial Encoder Resolution                       | 02:8192_FMT        | -    |
| 12 | PASEL         | Backup Type Absolute Encoder Function Sel...    | 01:Incremental_... | -    |
| 14 | INTTIM        | Waiting Time for Initial Process                | 00:Disabled        | -    |
| 18 | 0x20FC:M...   | Modulo initialization warning detection setting |                    | 0    |
| 19 | AxisEnable    | Enable axis setting                             | 00:Disabled        |      |
| 1A | 0x20FD-4:...  | Main Power Supply Voltage                       | 03:48V             |      |

\*The values in the *Input Value* Column will be blank once the parameter settings are reflected.


30 Click **Group C [Encoder/Alarm]** in the Group. Group C [Encoder/Alarm] is displayed in the List of parameters. Check that the following parameter is set in the *Present Setting Value* Column.

- Flag for the axis between the interlock mask: 00:Enable



31 Select **Close** from the File Menu.


\*The Setting of each group Parameter (Axis 2) Window is closed.



32 In the same way as steps 24 to 31, set the following parameters for the other axes (Ax3 and Ax4).


- Enable axis setting: **00:Disabled**
- Flag for the axis between the interlock mask: **00:Enable**

33 Select **Exit** from the Project Menu of the main window.



34 A dialog box is displayed confirming whether to save the project.  
If not required, click **No**.

\*If you would like to save the parameter settings, click **Yes**.



35 Turn OFF Control and Main circuit power supplies, then turn them back ON.

\*The changed parameter values will be valid after turning the power supplies OFF and then back ON.

## 7.4. Controller Setup

Set up the Controller.

The settings described here are made beforehand in the project file that is described in *Section 9. Appendix 1: Procedures Using the Project File*.

### WARNING

Depending on the Controller status, unexpected operation of the Motion Control Device may occur and result in injury when you turn ON the Controller. Focus on safety when you turn ON the power supply.



### Precautions for Correct Use


Make sure that the Ethernet cable is connected to both devices before performing the following procedure. If not, turn OFF the devices, and then connect the Ethernet cable.

#### 7.4.1. Setting the EtherCAT Network Configuration


Set the EtherCAT network configuration.

1 Turn ON Controller.

2 Select **Online** from the Controller Menu in Sysmac Studio.





When an online connection is established, a yellow line is displayed under the toolbar.



- 3 Right-click **Master** on the EtherCAT Tab Page of the Edit Pane, and select **Compare and Merge with Actual Network Configuration**.


\*If the EtherCAT Tab Page is not displayed, double-click **EtherCAT** under **Configurations and Setup** in the Multiview Explorer.

A screen is displayed stating "Get information is being executed".





- 4 The Compare and Merge with Actual Network Configuration Dialog Box is displayed. The node address 1 and SanyoDenki RF2 EtherCAT Rev:0x00000000 are added to the Actual network configuration after the comparison.




Click **Apply actual network configuration**.



- 5 A confirmation dialog box is displayed. Check the contents and click **Apply**.

The dialog box on the right is displayed. Check the contents and click **Close**.



- |  |   |
|--|---|
| <p>6 As a node address 1 slave, E001 SanyoDenki RF2 EtherCAT Rev:0x00000000 is added to the Network configuration on Sysmac Studio.</p> <p>Check that the data above is added. Click <b>Close</b>.</p> | <br>  |
| <p>7 The node address 1 and E001 SanyoDenki RF2 EtherCAT Rev:0x00000000 are added to the EtherCAT Tab Page of the Edit Pane.</p>   |   |
| <p>8 Select <b>Offline</b> from the Controller Menu.</p> <p>The yellow line under the toolbar disappears.</p>  | <br><br> |

7.4.2. PDO Map Settings

Map the objects to PDOs for the MC Function Module.





**Additional Information**

The objects described in 6.1.2. *PDO Mapping* are available for the MC Function Module of the Controller from among the objects supported by the Motion Control Device.



Refer to *Section 10. Appendix 2: MC Instructions and PDO Entries* for details on the objects available for the MC Function Module.

- 1 Select the node address 1 slave added on the EtherCAT Tab Page in the previous procedure 7.4.1.


Check that Enable Distributed Clock is set to Enabled (DC-Synchronous (SYNC0)).



- 2 Click **Edit PDO Map Settings** in the *PDO Map Settings* Field.




3 The Edit PDO Map Settings Dialog Box is displayed.



4 Change the PDO mapping for Ax1 by following the steps below.


Click *Outputs(Ax1)* that has been selected by default. "PDO entries included in Outputs(Ax1)" is displayed on the right side of the dialog box.




\*In this guide, the procedure is described based on the PDOs mapped by default. You can also select a mapping different from the one in this guide.






5 Check that the following objects are set.

- 0x6040:00
- 0x607A:00
- 0x60FF:00
- 0x6060:00
- 0x0000:00



6 Select *0x60FF:00* and click **Add PDO Entry**.



- 7 The Edit PDO Map Settings Dialog Box is displayed.
- Among the objects listed in 6.1.2. *PDO Mapping*, select the following object that is not yet set.
- 0x6071:00
- Click **OK**.
- 
- 8 Check that the object is added.
- 
- | Index     | Size     | Data type | PDO entry name     | Comment |
|-----------|----------|-----------|--------------------|---------|
| 0x6040:00 | 16 [bit] | UINT      | Control word       |         |
| 0x607A:00 | 32 [bit] | DINT      | Target position    |         |
| 0x60FF:00 | 32 [bit] | DINT      | Target velocity    |         |
| 0x6071:00 | 16 [bit] | INT       | Target torque      | ---     |
| 0x6060:00 | 8 [bit]  | SINT      | Modes of operation |         |
| 0x0000:00 | 8 [bit]  | ---       | ---                | ---     |
- 9 In the same way as steps 6 to 8, add the following objects.
- 0x60E0:00
  - 0x60E1:00
  - 0x60B8:00
- 
- | Index     | Size     | Data type | PDO entry name        | Comment |
|-----------|----------|-----------|-----------------------|---------|
| 0x6040:00 | 16 [bit] | UINT      | Control word          |         |
| 0x607A:00 | 32 [bit] | DINT      | Target position       |         |
| 0x60FF:00 | 32 [bit] | DINT      | Target velocity       |         |
| 0x6071:00 | 16 [bit] | INT       | Target torque         |         |
| 0x6060:00 | 8 [bit]  | SINT      | Modes of operation    |         |
| 0x0000:00 | 8 [bit]  | ---       | ---                   | ---     |
| 0x60E0:00 | 16 [bit] | UINT      | Positive torque limit |         |
| 0x60E1:00 | 16 [bit] | UINT      | Negative torque limit |         |
| 0x60B8:00 | 16 [bit] | UINT      | Touch probe function  |         |
- 10 Click *Inputs(Ax1)* that has been selected by default.
- "PDO entries included in Inputs(Ax1)" is displayed on the right side of the dialog box.
- 
- | Index     | Size     | Data type | PDO entry name         | Comment |
|-----------|----------|-----------|------------------------|---------|
| 0x6041:00 | 16 [bit] | UINT      | Status word            |         |
| 0x6064:00 | 32 [bit] | DINT      | Position actual val... |         |
| 0x606C:00 | 32 [bit] | DINT      | Velocity actual val... |         |
| 0x6061:00 | 8 [bit]  | SINT      | Modes of operati...    |         |
| 0x0000:00 | 8 [bit]  | ---       | ---                    | ---     |
- 11 Check that the following objects are set.
- 0x6041:00
  - 0x6064:00
  - 0x606C:00
  - 0x6061:00
  - 0x0000:00
- 
- | Index     | Size     | Data type | PDO entry name             | Comment |
|-----------|----------|-----------|----------------------------|---------|
| 0x6041:00 | 16 [bit] | UINT      | Status word                |         |
| 0x6064:00 | 32 [bit] | DINT      | Position actual value      |         |
| 0x606C:00 | 32 [bit] | DINT      | Velocity actual value      | ---     |
| 0x6061:00 | 8 [bit]  | SINT      | Modes of operation display |         |
| 0x0000:00 | 8 [bit]  | ---       | ---                        | ---     |

- 12 Delete the object that is not described in 6.1.2. *PDO Mapping*, in the following way. Select the following object and click **Delete PDO Entry**.
- 0x606C:00

PDO entries included in Inputs(Ax1)

| Index     | Size     | Data type | PDO entry name             | Comment |
|-----------|----------|-----------|----------------------------|---------|
| 0x6041:00 | 16 [bit] | UINT      | Status word                |         |
| 0x6064:00 | 32 [bit] | DINT      | Position actual value      |         |
| 0x606C:00 | 32 [bit] | DINT      | Velocity actual value      | ---     |
| 0x6061:00 | 8 [bit]  | SINT      | Modes of operation display |         |
| 0x0000:00 | 8 [bit]  | ---       | ---                        | ---     |

Buttons: Move Up, Move Down, Align, Edit PDO Entry, Add PDO Entry, Delete PDO Entry, OK, Cancel, Apply

- 13 Check that the object is deleted.

PDO entries included in Inputs(Ax1)

| Index     | Size     | Data type | PDO entry name             | Comment |
|-----------|----------|-----------|----------------------------|---------|
| 0x6041:00 | 16 [bit] | UINT      | Status word                |         |
| 0x6064:00 | 32 [bit] | DINT      | Position actual value      |         |
| 0x6061:00 | 8 [bit]  | SINT      | Modes of operation display |         |
| 0x0000:00 | 8 [bit]  | ---       | ---                        | ---     |

- 14 In the same way as steps 6 to 8, add the following objects.

- 0x6077:00
- 0x60B9:00
- 0x60BA:00
- 0x60BC:00
- 0x60FD:00
- 0x2100:00

PDO entries included in Inputs(Ax1)

| Index     | Size     | Data type | PDO entry name                        | Comment |
|-----------|----------|-----------|---------------------------------------|---------|
| 0x6041:00 | 16 [bit] | UINT      | Status word                           |         |
| 0x6064:00 | 32 [bit] | DINT      | Position actual value                 |         |
| 0x6077:00 | 16 [bit] | INT       | Torque actual value                   | ---     |
| 0x6061:00 | 8 [bit]  | SINT      | Modes of operation display            |         |
| 0x0000:00 | 8 [bit]  | ---       | ---                                   | ---     |
| 0x60B9:00 | 16 [bit] | UINT      | Touch probe status                    | ---     |
| 0x60BA:00 | 32 [bit] | DINT      | Touch probe position 1 positive value | ---     |
| 0x60BC:00 | 32 [bit] | DINT      | Touch probe position 2 positive value | ---     |
| 0x60FD:00 | 32 [bit] | UDINT     | Digital inputs                        | ---     |
| 0x2100:00 | 16 [bit] | UINT      | Status word 1                         | ---     |

- 15 Change the PDO mapping for the other axes (Ax2 to Ax4) by following the steps below. Display the output process data for Ax2 in the PDO Map.

PDO Map

Process Data Size : Input 496 [bit] / 11472 [bit]  
Output 448 [bit] / 11472 [bit]

| Selection                        | Input/Output | Name         | Flag     |
|----------------------------------|--------------|--------------|----------|
| <input type="radio"/>            | ---          | No option    | ---      |
| <input type="radio"/>            | Output       | Outputs(Ax2) | Editable |
| <input checked="" type="radio"/> | Output       | Outputs(Ax2) | Editable |
| <input type="radio"/>            | ---          | No option    | ---      |
| <input type="radio"/>            | Output       | Outputs(Ax2) | Editable |
| <input type="radio"/>            | ---          | No option    | ---      |
| <input type="radio"/>            | Output       | Outputs(Ax2) | Editable |
| <input checked="" type="radio"/> | ---          | No option    | ---      |
| <input type="radio"/>            | Output       | Outputs(Ax2) | Editable |
| <input type="radio"/>            | ---          | No option    | ---      |
| <input type="radio"/>            | Output       | Outputs(Ax3) | Editable |



Select *No option* for all the output process data for Ax2.

\*This guide does not use Ax2.

PDO Map

Process Data Size : Input 496 [bit] / 11472 [bit]  
Output 352 [bit] / 11472 [bit]

| Selection                        | Input/Output | Name         | Flag     |
|----------------------------------|--------------|--------------|----------|
| <input checked="" type="radio"/> | ---          | No option    | ---      |
| <input type="radio"/>            | Output       | Outputs(Ax2) | Editable |
| <input type="radio"/>            | Output       | Outputs(Ax2) | Editable |
| <input checked="" type="radio"/> | ---          | No option    | ---      |
| <input checked="" type="radio"/> | ---          | No option    | ---      |
| <input type="radio"/>            | Output       | Outputs(Ax2) | Editable |
| <input checked="" type="radio"/> | ---          | No option    | ---      |
| <input checked="" type="radio"/> | ---          | No option    | ---      |
| <input type="radio"/>            | Output       | Outputs(Ax2) | Editable |
| <input type="radio"/>            | ---          | No option    | ---      |
| <input type="radio"/>            | Output       | Outputs(Ax3) | Editable |


**16** In the same way as step 15, select *No option* for all the output process data for Ax3 and Ax4.

\*This guide does not use Ax3 and Ax4.

• Ax3



• Ax4




**17** In the same way as steps 15 and 16, select *No option* for all the input process data for the other axes (Ax2 to Ax4).

\*This guide does not use Ax2, Ax3 and Ax4


• Ax2




• Ax3



• Ax4



**18** Click **OK**.






19 The same PDO entries as described in 6.1.2. *PDO Mapping* are displayed in the *PDO Map Settings* Field.


| Item name                | Value   |
|--------------------------|---|
| Device name              | E001  |
| Model name               | SanyoDenki RF2 EtherCAT   |
| Product name             | RF2-EtherCAT (P0010959C01:25Jan,2017)   |
| Revision                 | 0x00000000  |
| PDO Communications Cycle | PDO Communications Cycle 1 (2000 us)  |
| Node Address             | 1   |
| Enable/Disable Settings  | Enabled   |
| Serial Number            | 0x00000000  |
| PDO Map Settings         | <div style="border: 1px solid red; padding: 5px;">                     0x6040:00 Outputs(Ax1)/Control word<br/>                     0x607A:00 Outputs(Ax1)/Target position<br/>                     0x60FF:00 Outputs(Ax1)/Target velocity<br/>                     0x6071:00 Outputs(Ax1)/Target torque<br/>                     0x6060:00 Outputs(Ax1)/Modes of operation<br/>                     0x60E0:00 Outputs(Ax1)/Positive torque limit<br/>                     0x60E1:00 Outputs(Ax1)/Negative torque limit<br/>                     0x60B8:00 Outputs(Ax1)/Touch probe function<br/>                     0x6041:00 Inputs(Ax1)/Status word<br/>                     0x6064:00 Inputs(Ax1)/Position actual value<br/>                     0x6077:00 Inputs(Ax1)/Torque actual value<br/>                     0x6061:00 Inputs(Ax1)/Modes of operation display<br/>                     0x60B9:00 Inputs(Ax1)/Touch probe status<br/>                     0x60BA:00 Inputs(Ax1)/Touch probe position 1 positive value<br/>                     0x60BC:00 Inputs(Ax1)/Touch probe position 2 positive value<br/>                     0x60FD:00 Inputs(Ax1)/Digital inputs<br/>                     0x2100:00 Inputs(Ax1)/Status word 1                 </div> |
|                          | <a href="#">Edit PDO Map Settings</a>   |
| Enable Distributed Clock | Enabled (DC-Synchronous(SYNCO))   |

### 7.4.3. Axis Settings for Motion Control

Set the axis for the MC Function Module.

|  |  |
|--|--|
| <p>1 Select <b>Configurations and Setup – Motion Control Setup – Axis Settings</b> in the Multiview Explorer.<br/>Right-click <b>Axis Settings</b> and select <b>Add – Motion Control Axis</b> from the menu.</p>  |    |
| <p>2 MC_Axis000 (0,MC1) is added under Motion Control Setup – Axis Settings.<br/>Right-click <b>MC_Axis000 (0,MC1)</b> and select <b>Edit</b> from the menu.</p> <p>*For NJ-series Controllers, the axis name displayed in Sysmac Studio is "MC_Axis000 (0)".</p>  |    |
| <p>3 The MC_Axis000 (0,MC1) Tab Page is displayed in the Edit Pane.<br/>Click the <b>Axis Basic Settings</b> Button.</p>   |   |
| <p>4 Enter or select the following values from the pull-down list to make the axis basic settings.</p> <ul style="list-style-type: none"> <li>• Axis number: 0</li> <li>• Axis use: <b>Used axis</b></li> <li>• Axis type: <b>Servo axis</b></li> <li>• Feedback control: <ul style="list-style-type: none"> <li><b>No control loop</b></li> </ul> </li> <li>• Output device 1: <ul style="list-style-type: none"> <li><b>Node:1SanyoDenki RF2 EtherCAT(E001)</b></li> </ul> </li> </ul> |  |


5 Click **Detailed Settings**.



Click the + Button to the left of the three function names to expand.




6 The list of function names is expanded.



7 Open the pull-down list in the *Device* Column for 1.Controlword.

Select **Node:1SanyoDenki RF2 EtherCAT(E001)**.



Select the following object from the pull-down list in the *Process Data* Column.

• **6040h-00.0**



- 8 Likewise, as shown in the figure below, set the device and process data for the other functions by referring to 6.1.5. *Axis Settings for PDO Entries*.

Select **Node:1SanyoDenki RF2 EtherCAT(E001)** for the device that process data needs to be assigned to.

Select **<Not assigned>** for the device that process data does not needs to be assigned to.

| Function Name                                | Device                                 | Process Data                                      |
|--|--|---|
| - Output (Controller to Device)              |  |   |
| ★ 1. Controlword                             | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 6040h-00.0(Outputs(Ax1)_Control word_6040_00)     |
| ★ 3. Target position                         | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 607Ah-00.0(Outputs(Ax1)_Target position_607A_0)   |
| 5. Target velocity                           | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 60FFh-00.0(Outputs(Ax1)_Target velocity_60FF_00)  |
| 7. Target torque                             | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 6071h-00.0(Outputs(Ax1)_Target torque_6071_00)    |
| 9. Max profile Velocity                      | <Not assigned>                         | <Not assigned>                                    |
| 11. Modes of operation                       | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 6060h-00.0(Outputs(Ax1)_Modes of operation_60)    |
| 15. Positive torque limit value              | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 60E0h-00.0(Outputs(Ax1)_Positive torque limit_60) |
| 16. Negative torque limit value              | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 60E1h-00.0(Outputs(Ax1)_Negative torque limit_6)  |
| 21. Touch probe function                     | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 6088h-00.0(Outputs(Ax1)_Touch probe function_6)   |
| 44. Software Switch of Encoder's Input Slave | <Not assigned>                         | <Not assigned>                                    |
| - Input (Device to Controller)               |  |   |
| ★ 22. Statusword                             | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 6041h-00.0(Inputs(Ax1)_Status word_6041_00)       |
| ★ 23. Position actual value                  | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 6064h-00.0(Inputs(Ax1)_Position actual value_606) |
| 24. Velocity actual value                    | <Not assigned>                         | <Not assigned>                                    |
| 25. Torque actual value                      | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 6077h-00.0(Inputs(Ax1)_Torque actual value_6077)  |
| 27. Modes of operation display               | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 6061h-00.0(Inputs(Ax1)_Modes of operation displ)  |
| 40. Touch probe status                       | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 6089h-00.0(Inputs(Ax1)_Touch probe status_6089)   |
| 41. Touch probe pos1 pos value               | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 60BAh-00.0(Inputs(Ax1)_Touch probe position 1 p)  |
| 42. Touch probe pos2 pos value               | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 60BCh-00.0(Inputs(Ax1)_Touch probe position 2 p)  |
| 43. Error code                               | <Not assigned>                         | <Not assigned>                                    |
| 45. Status of Encoder's Input Slave          | <Not assigned>                         | <Not assigned>                                    |
| 46. Reference Position for csp               | <Not assigned>                         | <Not assigned>                                    |
| - Digital inputs                             |  |   |
| 28. Positive limit switch                    | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 60FDh-00.18(Inputs(Ax1)_Digital inputs_60FD_00)   |
| 29. Negative limit switch                    | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 60FDh-00.19(Inputs(Ax1)_Digital inputs_60FD_00)   |
| 30. Immediate Stop Input                     | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 60FDh-00.21(Inputs(Ax1)_Digital inputs_60FD_00)   |
| 32. Encoder Phase Z Detection                | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 2100h-00.2(Inputs(Ax1)_Status word 1_2100_00)     |
| 33. Home switch                              | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 60FDh-00.20(Inputs(Ax1)_Digital inputs_60FD_00)   |
| 37. External Latch Input 1                   | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 60FDh-00.16(Inputs(Ax1)_Digital inputs_60FD_00)   |
| 38. External Latch Input 2                   | Node : 1 SanyoDenki RF2 EtherCAT(E001) | 60FDh-00.17(Inputs(Ax1)_Digital inputs_60FD_00)   |





### 7.4.4. Creating an Operation Check Program

Create a program to check the operation.


The MC\_Power instruction is used as an example in this program.

For information on MC instructions, refer to the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).


For details on the program in ST (structured text) language, refer to *Section 11. Appendix 3: Program*.

|  |  |
|--|--|
| <p>1 Select <b>Programming – POU’s – Programs – Program0</b> in the Multiview Explorer.<br/>Right-click <b>Program0</b> and select <b>Delete</b> from the menu.</p> <p>*The default "Program0" is automatically created in ladder language. It is not used in this guide because a program in ST language is manually created and used, as described in the following steps.</p> <p>The Delete Dialog Box is displayed. Click <b>Yes</b>.</p> <p>Program0 is deleted from Programming in the Multiview Explorer.</p> |   |
| <p>2 Right-click <b>Programs</b> under <b>Programming – POU’s</b> and select <b>Add – ST</b> from the menu.</p>  |  |
| <p>3 Double-click <b>Program0</b> added in the Multiview Explorer.<br/>The Program0 Tab Page is displayed in the Edit Pane.</p>  |  |
| <p>4 Click the <b>Up Arrow</b> Button in the <i>Variables</i> Field.</p>   |  |

5 The Internals Side Tab is displayed in the variable table.




Click on a space to create an entry cell in the *Name* Column.




Enter *Input\_Start* in the *Name* Column, and check that *BOOL* is displayed in the *Data Type* Column.




6 After entering, right-click and select **Create New** from the menu.




A new variable can be entered.



Enter *MC\_Power\_instance* in the *Name* Column.




Enter *MC\_Power* in the *Data Type* Column.



7 In the same way as step 6, enter the following data in newly created cells of the columns on the Internals Side Tab Page.

- *Local\_Power\_Enable*: *BOOL*
- *Output\_Power\_Status*: *BOOL*
- *Output\_Power\_Busy*: *BOOL*
- *Output\_Power\_Error*: *BOOL*
- *Output\_Power\_ErrorID*: *WORD*



8 Select the **Externals** Side Tab.

| Internals | Name                           | Data Type | Constant | Comment |
|-----------|--------------------------------|-----------|----------|---------|
| Externals | Empty. Click here to add Item. |           |          |         |



In the same way as steps 5 and 6, enter the following variable names in newly created cells of the *Name* Column on the Externals Side Tab Page.

The data types are automatically set.

- *\_EC\_PDslavTbl*
- *MC\_Axis000*
- *\_EC\_CommErrTbl*

| Internals | Name                  | Data Type             | Constant                            | Comment |
|-----------|-----------------------|-----------------------|-------------------------------------|---------|
| Externals | <i>_EC_PDslavTbl</i>  | ARRAY[1..192] OF BOOL | <input checked="" type="checkbox"/> |         |
|           | <i>MC_Axis000</i>     | <i>_s</i> AXIS_REF    | <input checked="" type="checkbox"/> |         |
|           | <i>_EC_CommErrTbl</i> | ARRAY[1..192] OF BOOL | <input checked="" type="checkbox"/> |         |

9 Click the **Down Arrow** Button to close the variable table.

10 The programming area of the Program0 Tab Page is displayed again. Write a program with the MC instruction.

\*For details on how to use MC instructions, refer to the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508).

\*The program on the right is only given as an example. You must write a program according to the specifications of the Motion Control Device you use. Refer to *Section 11. Appendix 3: Program* for details on the program shown on the right.


```
(* Section 01: Motion Control Device Start/Stop *)
IF Input_Start
  AND _EC_PDslavTbl[MC_Axis000.Cfg.NodeAddress]
  AND NOT _EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress]
THEN
  IF NOT MC_Axis000.DrvStatus.ServoOn THEN
    Local_Power_Enable:= TRUE;
  END_IF;
ELSE Local_Power_Enable:= FALSE;
END_IF;

(* Section 02: Error Operation *)
IF MC_Axis000.MFaultLvl.Active THEN
  Local_Power_Enable:= FALSE;
END_IF;


(* Section 03: MC Instruction Execute *)
MC_Power_instance(
  Axis:= MC_Axis000,
  Enable := Local_Power_Enable,
  Status => Output_Power_Status,
  Busy => Output_Power_Busy,
  Error => Output_Power_Error,
  ErrorID => Output_Power_ErrorID);
```

11 Check that the exclamation marks (errors) disappear from the Multiview Explorer.


12 Double-click **Task Settings** under **Configurations and Setup** in the Multiview Explorer. The Task Settings Tab Page is displayed in the Edit Pane.




13 Click the **Program Assignment Settings** Button.




14 Click the **+** Button in the *Primary Task* Field.



An entry cell is displayed in the *Program name* Column. Select **Program0** from the pull-down list.



Program0 is set. Check that the initial status is Run.



### 7.4.5. Transferring the Project Data

Transfer the created project data to the Controller.

#### WARNING

Regardless of the operating mode of the CPU Unit, devices or machines may perform unexpected operation when you transfer any of the following data from Sysmac Studio: a user program, configuration data, setup data, device variables or values in memory used for CJ-series Units.

Always confirm safety at the destination node before you transfer the project data.



#### WARNING

If you use EtherCAT slave units, check the specifications of those slave units in manuals or other documentation and confirm that the system will not be adversely affected before you transfer parameters.



#### Caution

After you transfer the project data, the CPU Unit is restarted, and communications with the slave unit is cut off. During the period, the outputs of the slave unit behave according to the slave unit settings. The time that communications is cut off depends on the EtherCAT network configuration.


Before you transfer the project data, confirm that the slave unit settings will not adversely affect the system.




#### Additional Information







Refer to the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504) for information on how to handle errors and warnings that have occurred as results of a program check and building.

- 1 Select **Check All Programs** from the Project Menu.



- 2 The Build Tab Page is displayed. Check that "0 Errors" and "0 Warnings" are displayed.




|  |  |
|--|--|
| <p>3 Select <b>Rebuild Controller</b> from the Project Menu.</p>   |    |
| <p>4 The dialog box on the right is displayed. Confirm that there is no problem, and click <b>Yes</b>.</p>   |    |
| <p>5 Check that "0 Errors" and "0 Warnings" are displayed on the Build Tab Page.</p>   |    |
| <p>6 If you need to save the created project file, select <b>Export</b> from the File Menu.</p> <p><i>*Refer to Section 9. Appendix 1: Procedures Using the Project File if you use the exported data.</i></p> |   |
| <p>7 Select <b>Online</b> from the Controller Menu.</p> <p>When an online connection is established, a yellow line is displayed under the toolbar.</p>   |  |
| <p>8 Select <b>Synchronize</b> from the Controller Menu.</p>   |  |

9 The Synchronization Dialog Box is displayed.

Check that the data to transfer (example: NX102) is selected. Click **Transfer To Controller**.




\*After executing "Transfer To Controller", the Sysmac Studio data is transferred to Controller, and the data is synchronized.



10 A confirmation dialog box is displayed. Confirm that there is no problem, and click **Yes**.

A screen is displayed stating "Synchronizing".

A confirmation dialog box is displayed. Confirm that there is no problem, and click **Yes**.



11


As shown in the figure on the right, the font color that is used to display the synchronized data changes to the same color as the one used to specify "Synchronized".

Check that a message is displayed stating "The Synchronization process successfully finished".

Confirm that there is no problem, and click **Close**.

\*When the Sysmac Studio project data matches the Controller data, a message is displayed stating "The Synchronization process successfully finished".

\*If the synchronization fails, check the wiring and repeat from step 1.



### 7.5. Connection Status Check

Check the connection status of the EtherCAT network.

#### 7.5.1. Checking the Connection Status


Confirm that EtherCAT communications is performed normally.

- 1 Check with LED indicators on Controller that PDO communications via EtherCAT is performed normally.

The LED indicators in normal status are as follows:

- NET RUN: Green lit
- NET ERR: Not lit
- LINK/ACT: Yellow flashing

\*The NJ-series Controllers also have the same LED indicator status.




Built-in EtherCAT (Port 3) Status Indicators

- 2 Check the LED indicators on Servo Amplifier.

The LED indicators in normal status are as follows:

- RUN indicator: Green lit
- IN Link/Activity indicator: Green flickering
- ERR indicator: Not lit



### 7.5.2. Checking the Connection Status Using the Operation Check Program

Confirm that the Servo Amplifier is operated normally using the operation check program. The MC\_Power instruction is used in this program.

#### Caution

In this procedure, the operation of the Motion Control Device is checked, which may perform unexpectedly.

Ensure safety before you proceed with this operation check described here.

If you cannot ensure safety, do not proceed. When you perform this operation check, make sure to complete all the steps and make the output of the Slave Amplifier safe.



#### Caution

If you change the variable values on a Watch Tab Page when Sysmac Studio is online with the CPU Unit, the devices connected to the Controller may operate regardless of the operating mode of the CPU Unit.

Always ensure safety before you change the variable values on a Watch Tab Page when Sysmac Studio is online with the CPU Unit.




#### Caution


Please note that some functions of the MC Function Module may be unavailable, or available but different in behavior from OMRON Motion Control Devices due to the different specifications between non-OMRON and OMRON Motion Control Devices. Make sure to check *Section 8. Restrictions on Motion Control* in this guide when you design a system.








- 1 Check that RUN mode (operating mode of Controller) is displayed in the Controller Status Pane of Sysmac Studio.



If not, select **Mode – RUN Mode** from the Controller Menu to change the operating mode to RUN mode.



|  |   |
|--|---|
| <p>2 Select <b>Watch Tab Page</b> from the View Menu.</p>  |   |
| <p>3 The Watch (Project)1 Tab Page is displayed.</p>   |   |
| <p>4 Enter <i>Program0</i> in the <i>Name</i> Column.</p>  |   |
| <p>5 Click the <b>Down Arrow</b> Button to the left of Program0. The variables used in Program0 are displayed.</p> <p>*The order of variable names may be changed depending on the operating environment.</p>  |    |
| <p>6 Check with the following LED indicator on Servo Amplifier that Ax1 is in the "state of operation preparation completion". (operation-ready state)</p> <p>The LED indicator that indicates the state is as follows:<br/>         Amplifier status indicator ST1:<br/>         Green blinking with 256 ms cycle</p> |  <p>Amplifier status indicator ST1</p> |
| <p>7 With Sysmac Studio, click <b>TRUE</b> in the <i>Modify</i> Column for <i>Input_Start</i>. The online value is changed from False to True.</p> <p>*The MC_Power instruction is executed.</p>   |   |

- 8 Check that the following online values of the variables are displayed.
- Local\_Power\_Enable*: True  
(Indicates that the instruction is ready for execution.)
  - Output\_Power\_Busy*: True  
(Indicates that the instruction is being executed.)
  - Output\_Power\_Error*: False  
(Indicates that there is no error.)
  - Output\_Power\_ErrorID*: 0000  
(Indicates that there is no error.)
  - Output\_Power\_Status*: True  
(Indicates that Servo Amplifier is ready for operation.)

| Name                 | Online value | Modify     |
|----------------------|--------------|------------|
| Program0             |              |            |
| P_On                 | True         | TRUE FALSE |
| P_Off                | False        | TRUE FALSE |
| P_PRGER              | False        | TRUE FALSE |
| P_CY                 | False        | TRUE FALSE |
| P_First_RunMode      | False        | TRUE FALSE |
| P_First_Run          | False        | TRUE FALSE |
| Input_Start          | True         | TRUE FALSE |
| MC_Power_instance    |              |            |
| Local_Power_Enable   | True         | TRUE FALSE |
| Output_Power_Busy    | True         | TRUE FALSE |
| Output_Power_Error   | False        | TRUE FALSE |
| Output_Power_ErrorID | 0000         |            |
| Output_Power_Status  | True         | TRUE FALSE |

\*They indicate that the MC\_Power instruction is operating normally.

- 9 Click the **Down Arrow** Button to the left of *MC\_Axis000*.  
*DrvStatus* is displayed.  
Likewise, click the **Down Arrow** Button to the left of *DrvStatus*.

| Name        | Online value | Modify |
|-------------|--------------|--------|
| MC_Axis000  |              |        |
| ▶ Cfg       |              |        |
| ▶ Scale     |              |        |
| ▶ Status    |              |        |
| ▶ Details   |              |        |
| ▶ Dir       |              |        |
| ▶ DrvStatus |              |        |
| ▶ Cmd       |              |        |
| ▶ Act       |              |        |
| ▶ MFaultLvl |              |        |
| ▶ Obsr      |              |        |


- 10 Check that *ServoOn* is True.  
\*This indicates that the motor is energized.

| Name      | Online value | Modify     |
|-----------|--------------|------------|
| DrvStatus |              |            |
| ServoOn   | True         | TRUE FALSE |
| Ready     | True         | TRUE FALSE |
| MainPower | True         | TRUE FALSE |
| P_OT      | False        | TRUE FALSE |

11 Check with the following LED indicator on Servo Amplifier that Ax1 is in the "state of servo ON".

The LED indicator that indicates the state is as follows:  
 Amplifier status indicator ST1:  
 Green blinking with 1.024 s cycle

Amplifier status indicator ST1



\*The blinking cycle of the LED indicator is slower than the one described in step 6.

12 With Sysmac Studio, click **FALSE** in the *Modify* Column for *Input\_Start* on the Watch1 Tab Page.

The online value is changed from True to False.

| Name            | Online value | Modify |       |
|-----------------|--------------|--------|-------|
| Program0        |              |        |       |
| P_On            | True         | TRUE   | FALSE |
| P_Off           | False        | TRUE   | FALSE |
| P_PRGER         | False        | TRUE   | FALSE |
| P_CY            | False        | TRUE   | FALSE |
| P_First_RunMode | False        | TRUE   | FALSE |
| P_First_Run     | False        | TRUE   | FALSE |
| Input_Start     | False        | TRUE   | FALSE |

\*The MC\_Power instruction is ended.

13 Check that the following online values of the variables are displayed.

- Local\_Power\_Enable*: False  
(Indicates that the instruction is not executed.)
- Output\_Power\_Busy*: False  
(Indicates that the instruction is buffered for execution.)
- Output\_Power\_Error*: False  
(Indicates that there is no error.)
- Output\_Power\_ErrorID*: 0000  
(Indicates that there is no error.)
- Output\_Power\_Status*: False  
(Indicates that Servo Amplifier is not ready for operation.)

| Name                 | Online value | Modify |       |
|----------------------|--------------|--------|-------|
| Program0             |              |        |       |
| P_On                 | True         | TRUE   | FALSE |
| P_Off                | False        | TRUE   | FALSE |
| P_PRGER              | False        | TRUE   | FALSE |
| P_CY                 | False        | TRUE   | FALSE |
| P_First_RunMode      | False        | TRUE   | FALSE |
| P_First_Run          | False        | TRUE   | FALSE |
| Input_Start          | False        | TRUE   | FALSE |
| MC_Power_instance    |              |        |       |
| Local_Power_Enable   | False        | TRUE   | FALSE |
| Output_Power_Busy    | False        | TRUE   | FALSE |
| Output_Power_Error   | False        | TRUE   | FALSE |
| Output_Power_ErrorID | 0000         |        |       |
| Output_Power_Status  | False        | TRUE   | FALSE |

\*They indicate that the MC\_Power instruction has been properly ended.

14 Check that False is displayed in the *Online value* Column for *ServoOn* under *MC\_Axis000 – DrvStatus*.

\*This indicates that the motor is not energized.

| Name        | Online value | Modify     |
|-------------|--------------|------------|
| ▼ DrvStatus |              |            |
| ServoOn     | False        | TRUE FALSE |
| Ready       | True         | TRUE FALSE |
| MainPower   | True         | TRUE FALSE |
| P_OT        | False        | TRUE FALSE |

15 Check with the following LED indicator on Servo Amplifier that Ax1 is in the "state of operation preparation completion". (operation-ready state)


LED indicator that indicates the state is as follows:

Amplifier status indicator ST1:

Green blinking with 256 ms cycle

\*The blinking cycle of the LED indicator is faster than the one described in step 11.

Amplifier status indicator ST1



## 8. Restrictions on Motion Control

This section describes restrictions on when the Servo Amplifier that is connected to the Controller via EtherCAT is used as a motion control axis for the MC Function Module of the Controller.

### Caution

Some functions of the MC Function Module may be unavailable, or available but different in behavior from OMRON Motion Control Devices due to the different specifications between non-OMRON and OMRON Motion Control Devices. Those functions may cause unexpected operation of the Motion Control Device, resulting in injury. Carefully check differences before using the functions of the MC Function Module that are different in behavior from OMRON Motion Control Devices. Do not use the functions that are unavailable for use.



#### Additional Information

For NX1P2 and NX102 Controllers, a Servo Drive can be used as a single-axis position control axis. For information on the differences between the single-axis position control axis and the motion control axis, refer to the *NJ/NX-series CPU Unit Motion Control User's Manual* (Cat. No. W507).

### 8.1. List of Restrictions

The following table shows the restrictions on when you use the Servo Amplifier connected to the Controller.

| Item           | Function restricted in use and its status  | Details      |
|----------------|--|--------------|
| Axis variable  | <b>DrvStatus.ILA (Drive Internal Limiting)</b><br>The conditions to change this axis variable to TRUE depend on the specifications of a Motion Control Device defined by a manufacturer.   | Refer to 8.2 |
| MC instruction | <b>Automatic Torque Limit Function of the MC_Home and MC_HomeWithParameter Instructions</b><br>The automatic torque limit function of these MC instructions cannot work.   | Refer to 8.3 |
|                | <b>Velocity Limit Function of the MC_TorqueControl Instruction (Cyclic Synchronous Torque Control)</b><br>The velocity limit function of this MC instruction cannot work.  |              |
| Others         | <b>Stop Processing During the Cyclic Synchronous Torque Control</b><br>When performing a stop that is triggered by the MC_Stop instruction or an error during Cyclic Synchronous Torque Control (MC_TorqueControl instruction in execution), stop processing is performed differently from that of OMRON Motion Control Devices. | Refer to 8.4 |
|                | <b>MC Test Run</b><br>This function cannot be used.  |              |

## 8.2. Axis Variable

---

The restriction on the axis variable is described below.

### 8.2.1. DrvStatus.ILA (Drive Internal Limiting)

DrvStatus.ILA shows the status of bit 11 (internal limit active) of the Status word (6041 hex). The conditions for this axis variable to change to TRUE depend on the specifications of a Motion Control Device defined by a manufacturer.

Refer to 4) *Status Word* in 5.4. *PDS FSA* of the *SANMOTION AC SERVO SYSTEMS R ADVANCED MODEL TYPE F With EtherCAT Interface Type H For Rotary Motor, Linear Motor Instruction Manual* (M0011195) for information on the conditions for this axis variable to change to TRUE.

## 8.3. MC Instruction

---

The restrictions on the MC instructions are described below.

### 8.3.1. Automatic Torque Limit Function of the MC\_Home and MC\_HomeWithParameter Instructions

The OMRON Motion Control Devices can use the automatic torque limit function of the MC\_Home or MC\_HomeWithParameter instruction for the Homing Operation Mode "Proximity reverse turn/holding time" or "No home proximity input/holding home input".

The automatic torque limit function is unique to OMRON.

This function does not work for non-OMRON Motion Control Devices.



#### Additional Information

---

If you use a non-OMRON Motion Control Device and attempt to use the automatic torque limit function of the MC\_Home or MC\_HomeWithParameter instruction for the Homing Operation Mode "Proximity reverse turn/holding time" or "No home proximity input/holding home input", use the MC\_SetTorqueLimit instruction instead, or if the Motion Control Device has a function to perform the torque limit, create a program to activate the function via SDO communications.

---

### 8.3.2. Velocity Limit Function of the MC\_TorqueControl Instruction (Cyclic Synchronous Torque Control)

The OMRON Motion Control Devices can limit the maximum velocity of a Servo Motor by using the velocity limit function when the torque is controlled by the MC\_TorqueControl instruction (Cyclic Synchronous Torque Control).

The velocity limit function is performed according to OMRON's own specifications.

This function does not work for non-OMRON Motion Control Devices.



#### Additional Information

If you use the velocity limit function of the MC\_TorqueControl instruction (Cyclic Synchronous Torque Control) for non-OMRON Motion Control Devices, monitor the command current velocity or the actual current velocity in the axis variable.

In case that the velocity is high, create a program that corrects the target torque.

## 8.4. Others

The other restrictions are described below.

### 8.4.1. Stop Processing During the Cyclic Synchronous Torque Control

When you use a Non-OMRON Motion Control Device and perform a stop that is triggered by the MC\_Stop instruction or an error during Cyclic Synchronous Torque Control (MC\_TorqueControl instruction in execution), stop processing is performed differently from that of OMRON Motion Control Devices.

| Motion Control Device | Stop Processing During the Cyclic Synchronous Torque Control  |
|-----------------------|---|
| Non-OMRON             | <p>Stop processing is performed in the following way.</p> <ol style="list-style-type: none"> <li>1. The control mode of the Motion Control Device is changed to Cyclic Synchronous Position (CSP).</li> <li>2. At the actual position (as the starting point) where the control mode is changed to Cyclic Synchronous Position (CSP), the Motion Control Device outputs the command position that allows the current velocity to change to 0 by calculating from the current velocity and given deceleration rate.</li> <li>3. The Motion Control Device decelerates to a stop at the given deceleration rate.</li> </ol> |
| OMRON                 | <p>Stop processing is performed in the following way.</p> <ol style="list-style-type: none"> <li>1. The velocity limit value is immediately changed to 0.</li> <li>2. After the velocity limit value is changed to 0, the MC Function Module confirms that the actual position meets the stopping criterion.</li> <li>3. After the confirmation, the control mode is changed from Cyclic Synchronous Torque (CST) to Cyclic Synchronous Position (CSP).</li> <li>4. The Motion Control Device performs an immediate stop.</li> </ol>  |

### 8.4.2. MC Test Run

The MC test run is a dedicated function of Sysmac Studio for OMRON Motion Control Devices.

This function cannot be used for non-OMRON Motion Control Devices.

## 9. Appendix 1: Procedures Using the Project File

This section describes the procedures when using the following project file or the project file you exported in 7.4. *Controller Setup*.

Obtain the project file with a latest version from OMRON.

The project file specified below has been created for NX-series Controllers. If you use an NJ-series Controller, change the device information displayed in the Change Device Dialog Box of Sysmac Studio.


| Name  | File name                                | Version  |
|---|--|----------|
| Sysmac Studio project file<br>(extension: csm2) | P707_NX_ECATCH_SanyoDK_RF2_V100.<br>csm2 | Ver.1.00 |

The following table lists references for the settings made in the project file.

| Item   | Reference                                      |
|--|--|
| Communications parameter settings                    | 6.1. Parameters                                |
| How to set communications parameters                 | 7.4. Controller Setup                          |
| Relationship between PDO entries and MC instructions | 10.Appendix 2: MC Instructions and PDO Entries |
| Details on the operation check program               | 11.Appendix 3: Program                         |

### 9.1. Work Flow

Take the following steps with the prepared project file to connect the Controller and the Servo Amplifier via EtherCAT and to operate the Motion Control Device using the MC instruction for the Controller. Refer back to each of the following procedures for details except for 9.2. *Controller Setup* boxed in red.








## 9.2. Controller Setup

Set up the Controller using the project file.

Perform 7.2. *Preparation for Controller Setup* and 7.3. *SANYO DENKI Servo Amplifier Setup* before following the steps.

### 9.2.1. Importing the Project File

Import the project file to Sysmac Studio.


|  |  |
|--|--|
| <p>1 Select <b>Import</b> from the File Menu.</p>  |    |
| <p>2 The Import file Dialog Box is displayed.<br/>Select <i>P707_NX_ECAT_SanyoDK_RF2_V100.csm2</i> (project file) or the project file you exported in 7.4. <i>Controller Setup</i>. Click <b>Open</b>.</p>   |   |
| <p>3 A confirmation dialog box is displayed asking you whether to save the project.<br/>Click <b>No</b> if you do not need to save.</p>  |  |
| <p>4 The P707_NX_ECAT_SanyoDK_RF2_V100 project is displayed.<br/><br/>*If an error message is displayed stating "Failed to Load Descendants", change the version of Sysmac Studio to the version specified in 5.2. <i>Device Configuration</i> or to a higher version.</p> |  |
| <p>5 Select <b>Change Device</b> from the Controller Menu.</p>   |  |

6 The Change Device Dialog Box is displayed.  
Check that the *Device* and *Version* Fields are set as shown on the right.


Click **Cancel**.

\*If the settings are different, select the items from the pull-down list, and click **OK**.

\* The setting items and the supported range of values vary depending on the Controller model. Refer to *A-10 Changing models among NJ-, NX-, and NY-series Controllers* of the *Sysmac Studio Version 1 Operation Manual* (Cat. No. W504) for details.



7 If you change the settings in step 6, "Build finished" is displayed on the Output Tab Page.





**Precautions for Correct Use**


If an error occurs, refer to the following troubleshooting tip.

The following screenshot is given only for explanation purposes. The data in the screenshot is different from those obtained with the applicable devices specified in this guide.

■ ESI file error

If the following dialog box is displayed, the information contained in the installed ESI file is different from the ESI in the project file. If the installed ESI file is the same as the one specified in 5.2. *Device Configuration*, click **Yes** and proceed to the next step.

If not, obtain the correct ESI file from the device manufacturer and repeat the procedures from 7.2.3. *Installing the ESI File*.



**9.2.2. Checking the EtherCAT Network Configuration**




Check the EtherCAT network configuration with Sysmac Studio.

Perform the following steps, and then follow 7.4.5. *Transferring the Project Data* and 7.5. *Connection Status Check*.




**Precautions for Correct Use**

Make sure that the Ethernet cable is connected to both devices before performing the following procedure. If not, turn OFF the devices, and then connect the Ethernet cable.


- 1 Turn ON Controller.
- 2 Double-click **EtherCAT** under **Configurations and Setup** in the Multiview Explorer.
 
- 3 The EtherCAT Tab Page is displayed in the Edit Pane. As a node address 1 slave, E001 SanyoDenki RF2 EtherCAT Rev:0x00000000 is displayed.
 
- 4 Select **Online** from the Controller Menu.
 

When an online connection is established, a yellow line is displayed under the toolbar.


5 Right-click **Master** on the EtherCAT Tab Page, and select **Compare and Merge with Actual Network Configuration**.



A screen is displayed stating "Get information is being executed".




6 The Compare and Merge with Actual Network Configuration Dialog Box is displayed. Check that the comparison result is "Matched". Click **Close** to close the dialog box.



\*If "Matched" is not displayed as the comparison result, follow the *Precautions for Correct Use* on the next page.

7 Select **Offline** from the Controller Menu.



The yellow line under the toolbar disappears.





**Precautions for Correct Use**


**If "Matched" is not displayed as the comparison result, do not click the Apply actual network configuration Button in the Compare and Merge with Actual Network Configuration Dialog Box.**

If you click the button, the settings including PDO map settings and axis settings in the project file will be cleared (initialized). If you accidentally click the button, repeat the procedures from 9.2.1. *Importing the Project File*. The following screenshots are given only for explanation purposes. The data in the screenshots are different from those obtained with the applicable devices specified in this guide.

If an error occurs, refer to the following troubleshooting tips.


■Error 1 (ESI file error)

If the following dialog box is displayed, the correct ESI file for your Motion Control Device is not installed. Obtain the correct ESI file from the device manufacturer and repeat the procedures from 7.2.3. *Installing the ESI File*.




■Error 2 (Node address mismatch)

If the node addresses do not match as shown below, repeat the procedures from 7.3. *SANYO DENKI Servo Amplifier Setup*.



■Error 3 (Revision mismatch)

If the revisions do not match as shown below, contact the device manufacturer to see if the ESI file is correct for the Motion Control Device. Or, prepare the device with the same revision as the one described in the ESI file, and repeat the procedures from 7.2.3. *Installing the ESI File*.



## 10. Appendix 2: MC Instructions and PDO Entries

The objects (PDO entries) that can be used for MC instructions have been assigned to the axis variables in the project file used in this guide.

Some objects are neither required to be assigned to axis variables nor to be mapped to PDOs, depending on the MC instructions you use. Refer to this section if you change the project file.



### Additional Information

For more information on PDO mappings, MC instructions and parameter settings for motion control, refer to the *NJ/NX-series CPU Unit Motion Control User's Manual* (Cat. No. W507) and the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508)

### 10.1. Required Objects for MC Instructions

To use MC instructions, the following objects have to be mapped to PDOs and be assigned to the axis variables. If even one of the required objects is not set, an error "Required Process Data Object Not Set" (error code 3460 hex) occurs.

| Input/Output | Function name of axis variable | Index  | PDO entry name        |
|--------------|--------------------------------|--------|-----------------------|
| Output       | 1.Controlword                  | 0x6040 | Control word          |
|              | 3.Target position              | 0x607A | Target position       |
| Input        | 22.Statusword                  | 0x6041 | Status word           |
|              | 23.Position actual value       | 0x6064 | Position actual value |



### Additional Information

If you use a CPU Unit version 1.09 or lower, "Modes of operation" (6060 hex) and "Modes of operation display" (6061 hex) are required to be mapped.

If you use a CPU Unit version 1.10 or higher, the operation differs depending on whether or not "Modes of operation" (6060 hex) and "Modes of operation display" (6061 hex) are mapped. Refer to the *NJ/NX-series Motion Control Instructions Reference Manual* (Cat. No. W508) for details.

**10.2. Required Objects for Specific MC Instructions**

If you use the following MC instructions, the objects required for those MC instructions have to be mapped to PDOs and be assigned to axis variables.

Output setting

| MC instruction                  | Function name of axis variable | 5.Target velocity | 7.Target torque | 21.Touch probe function (Latch function) | 15.Forward torque limit     | 16.Reverse torque limit     |
|---------------------------------|--------------------------------|-------------------|-----------------|--|-----------------------------|-----------------------------|
|                                 | Index                          | 0x60FF            | 0x6071          | 0x60B8                                   | 0x60E0                      | 0x60E1                      |
|                                 | PDO entry name                 | Target velocity   | Target torque   | Touch probe function                     | Positive torque limit value | Negative torque limit value |
| MC_Home<br>MC_HomeWithParameter |                                |                   |                 | Conditionally required <sup>*1</sup>     |                             |                             |
| MC_MoveFeed                     |                                |                   |                 | Conditionally required <sup>*2</sup>     |                             |                             |
| MC_MoveLink                     |                                |                   |                 | Conditionally required <sup>*3</sup>     |                             |                             |
| MC_TorqueControl                |                                |                   | Required        |  |                             |                             |
| MC_SetTorqueLimit               |                                |                   |                 |  | Required                    | Required                    |
| MC_TouchProbe                   |                                |                   |                 | Conditionally required <sup>*2</sup>     |                             |                             |
| MC_SyncMoveVelocity             |                                | Required          |                 |  |                             |                             |

\*1. Setting is not required for the following Homing Operation Modes: "Limit inputs only", "Proximity reverse turn/holding time" and "Zero position preset".

\*2. Setting is required when *Mode* is set to Drive Mode.

\*3. Setting is required when *LinkOption* (Synchronization Start Condition) is set to *\_mcTriggerDetection* and *Mode* is set to Drive Mode.

Input setting

| MC instruction                  | Function name of axis variable | 25.Torque actual value | 40.Touch probe status (Latch status) | 41.Touch probe pos1 pos value        | 42.Touch probe pos2 pos value        | Digital inputs                       |
|---------------------------------|--------------------------------|------------------------|--------------------------------------|--------------------------------------|--------------------------------------|--------------------------------------|
|                                 | Index                          | 0x6077                 | 0x60B9                               | 0x60BA                               | 0x60BC                               | 0x60FD                               |
|                                 | PDO entry name                 | Torque actual value    | Touch probe status                   | Touch probe pos1 pos value           | Touch probe pos2 pos value           | Digital inputs                       |
| MC_Home<br>MC_HomeWithParameter |                                |                        | Conditionally required <sup>*1</sup> | Conditionally required <sup>*1</sup> |                                      | Conditionally required <sup>*2</sup> |
| MC_MoveFeed                     |                                |                        | Conditionally required <sup>*3</sup> | Conditionally required <sup>*4</sup> | Conditionally required <sup>*5</sup> |                                      |
| MC_MoveLink                     |                                |                        | Conditionally required <sup>*6</sup> | Conditionally required <sup>*7</sup> | Conditionally required <sup>*8</sup> |                                      |
| MC_TorqueControl                |                                | Required               |                                      |                                      |                                      |                                      |
| MC_TouchProbe                   |                                |                        | Conditionally required <sup>*3</sup> | Conditionally required <sup>*4</sup> | Conditionally required <sup>*5</sup> |                                      |

\*1. Setting is not required for the following Homing Operation Modes: "Limit inputs only", "Proximity reverse turn/holding time" and "Zero position preset".

\*2. Setting is not required for the Homing Operation Mode "Zero position preset".

\*3. Setting is required when *Mode* is set to Drive Mode.

\*4. Setting is required when *Mode* is set to Drive Mode and *LatchID* is set to *\_mcLatch1* (Latch 1).

\*5. Setting is required when *Mode* is set to Drive Mode and *LatchID* is set to *\_mcLatch2* (Latch 2).

\*6. Setting is required when *LinkOption* (Synchronization Start Condition) is set to *\_mcTriggerDetection* and *Mode* is set to Drive Mode.

\*7. Setting is required when *LinkOption* (Synchronization Start Condition) is set to *\_mcTriggerDetection*, *Mode* is set to Drive Mode, and *LatchID* is set to *\_mcLatch1* (Latch 1).

\*8. Setting is required when *LinkOption* (Synchronization Start Condition) is set to *\_mcTriggerDetection*, *Mode* is set to Drive Mode, and *LatchID* is set to *\_mcLatch2* (Latch 2).

### 10.3. Digital Inputs Assignment

The assignment of the digital inputs object (60FDh) to the axis variables is described here. Please note that the assignment varies depending on the specifications of the Motion Control Device you use. The table below shows an example of an assignment using OMRON G5 series Servo Amplifiers. For details on each function, refer to the *AC SERVOMOTORS/SERVO DRIVES G5-series WITH BUILT-IN EtherCAT® COMMUNICATIONS User's Manual* (Cat. No. I576).

| Function name of axis variable     | Description   | Assignment for G5 series | Assignment in this guide |
|------------------------------------|---|--------------------------|--------------------------|
| 28.Forward Drive Prohibition Input | Assign the object that shows the ON/OFF status of the positive limit input    | 60FDh-00.1               | 60FDh-00.18              |
| 29.Reverse Drive Prohibition Input | Assign the object that shows the ON/OFF status of the negative limit input.   | 60FDh-00.0               | 60FDh-00.19              |
| 30.Immediate Stop Input            | Assign the object that shows the ON/OFF status of the immediate stop input.   | 60FDh-00.25              | 60FDh-00.21              |
| 32.Encoder Phase Z Detection       | Assign the object that shows the ON/OFF status of phase Z.                    | 60FDh-00.16              | 2100h-00.02              |
| 33.Origin Proximity Input          | Assign the object that shows the ON/OFF status of the home switch.            | 60FDh-00.2               | 60FDh-00.20              |
| 37.External Latch Input 1          | Assign the object that shows the ON/OFF status of the external latch input 1. | 60FDh-00.17              | 60FDh-00.16              |
| 38.External Latch Input 2          | Assign the object that shows the ON/OFF status of the external latch input 2. | 60FDh-00.18              | 60FDh-00.17              |

## 11. Appendix 3: Program

This section explains the operation check program used in this guide.

### 11.1. MC Instruction

The MC instruction used in the operation check program is described below.

#### 11.1.1. MC\_Power instruction

The MC\_Power instruction makes a Servo Drive ready to operate.

| Instruction | Meaning     | ST expression  |
|-------------|-------------|--|
| MC_Power    | Power servo | MC_Power_instance ( Axis := parameter,<br>Enable := parameter,<br>Status => parameter,<br>Busy => parameter,<br>Error => parameter,<br>ErrorID =>parameter<br>); |

#### Input variable

| Name   | Meaning | Data type | Valid range   | Default setting | Description   |
|--------|---------|-----------|---------------|-----------------|---|
| Enable | Enable  | BOOL      | TRUE or FALSE | FALSE           | The device is ready for operation when <i>Enable</i> is TRUE, and not ready when it is FALSE. |

#### Output variables

| Name    | Meaning    | Data type | Valid range   | Description   |
|---------|------------|-----------|---------------|---|
| Status  | Servo ON   | BOOL      | TRUE or FALSE | TRUE when the device is ready for operation.  |
| Busy    | Executing  | BOOL      | TRUE or FALSE | TRUE when the instruction is acknowledged.  |
| Error   | Error      | BOOL      | TRUE or FALSE | TRUE while there is an error.   |
| ErrorID | Error Code | WORD      | *1            | It contains the error code when an error occurs. A value of 16#0000 <sup>*2</sup> indicates normal execution. |

\*1. Refer to A-1 Error Codes of the NJ/NX-series Motion Control Instructions Reference Manual (Cat. No. W508).

\*2. 16#0000 indicates 0000 in hexadecimal.

#### In-out variable

| Name | Meaning | Data type  | Valid range | Description         |
|------|---------|------------|-------------|---------------------|
| Axis | Axis    | _sAXIS_REF | —           | Specify the axis.*1 |

\*1. Specify an axis variable that was created in the Axis Basic Settings of Sysmac Studio. (Default: MC\_Axis\*\*\*).

## 11.2. Program (ST Language)

The program written in ST language to check the operation is described below.

### 11.2.1. Details on the Program

The details on the operation check program are shown below.

| Processing |                                  |  |
|------------|----------------------------------|--|
| Section    | Processing name                  | Processing   |
| Section 01 | Motion Control Device Start/Stop | Changes the value of the start flag for <i>MC_Power_instance</i> to TRUE or FALSE according to the value (TRUE or FALSE) of <i>Input_Start</i> .<br>Using system-defined variables, determines whether PDO communications is performed normally. |
| Section 02 | Error Operation                  | Checks the system-defined variables, and detects if a minor fault level error occurs. This processing stops the execution of <i>MC_Power</i> when an error is detected.  |
| Section 03 | MC Instruction Execute           | Executes <i>MC_Power_instance</i> .  |

Source code

```
(* Section 01: Motion Control Device Start/Stop *)
IF Input_Start
  AND _EC_PDslavTbl[MC_Axis000.Cfg.NodeAddress]
  AND NOT _EC_CommErrTbl[MC_Axis000.Cfg.NodeAddress] THEN
  IF NOT MC_Axis000.DrvStatus.ServoOn THEN
    Local_Power_Enable:= TRUE;
  END_IF;
ELSE Local_Power_Enable:= FALSE;
END_IF;

(* Section 02: Error Operation *)
IF MC_Axis000.MFaultLvl.Active THEN
  Local_Power_Enable:= FALSE;
END_IF;

(* Section 03: MC Instruction Execute *)
MC_Power_instance(
  Axis := MC_Axis000,
  Enable := Local_Power_Enable,
  Status => Output_Power_Status,
  Busy => Output_Power_Busy,
  Error => Output_Power_Error,
  ErrorID => Output_Power_ErrorID);
```

### 11.2.2. Lists of Variables

The variables used in the operation check program are listed below.

#### Internal variables

| Name                 | Data type | Description   |
|----------------------|-----------|---|
| Input_Start          | BOOL      | This flag is used to execute or stop the function provided by the operation check program. TRUE during the execution. FALSE during the stop.  |
| MC_Power_instance    | MC_Power  | This is an instance to execute the MC_Power instruction (function block).   |
| Local_Power_Enable   | BOOL      | This variable is assigned to the <i>Enable</i> input variable of the MC_Power instruction. The device is ready for operation when <i>Enable</i> is TRUE, and not ready when it is FALSE.                  |
| Output_Power_Status  | BOOL      | This variable is assigned to the <i>Status</i> (Servo ON) output variable of the MC_Power instruction. TRUE when the device is ready for operation.   |
| Output_Power_Busy    | BOOL      | This variable is assigned to the <i>Busy</i> (Executing) output variable of the MC_Power instruction. TRUE when the instruction is acknowledged.  |
| Output_Power_Error   | BOOL      | This variable is assigned to the <i>Error</i> output variable of the MC_Power instruction. TRUE while there is an error.  |
| Output_Power_ErrorID | WORD      | This variable is assigned to the <i>ErrorID</i> output variable of the MC_Power instruction. It contains the error code when an error occurs. A value of 16#0000 <sup>*1</sup> indicates normal execution |

\*1. 16#0000 indicates 0000 in hexadecimal.

#### External variables

| Name           | Meaning                                | Data type                | Description  |
|----------------|--|--------------------------|--|
| _EC_PDSlaveTbl | Process Data Communicating Slave Table | ARRAY[1..192]<br>OF BOOL | This table indicates the slaves that are performing process data communications. Slaves are given in the table in the order of slave node addresses.<br>The element for a slave is TRUE if process data of the corresponding slave is enabled (operational) for both slave inputs and outputs. |
| _EC_CommErrTbl | Communications Error Slave Table       | ARRAY[1..192]<br>OF BOOL | Slaves are given in the table in the order of slave node addresses.<br>The corresponding slave element is TRUE if the master detected an error for the slave.  |
| MC_Axis000     | Axis 0                                 | _sAXIS_REF               | Axis variable for axis 0   |
| DrvStatus      | Servo Amplifier status                 | _sAXIS_REF_S<br>TA_DRV   | Gives the status of the Servo Amplifier.   |
| ServoOn        | Servo ON                               | BOOL                     | TRUE when the Servo Motor is powered.  |

## 12. Revision History

| Revision code | Date of revision | Description of revision |
|---------------|------------------|-------------------------|
| 01            | October 2018     | First edition           |
|               |                  |                         |
|               |                  |                         |



**OMRON Corporation Industrial Automation Company**

Tokyo, JAPAN

Contact: [www.ia.omron.com](http://www.ia.omron.com)

**Regional Headquarters**

**OMRON EUROPE B.V.**

Wegalaan 67-69, 2132 JD Hoofddorp  
The Netherlands  
Tel: (31)2356-81-300/Fax: (31)2356-81-388

**OMRON ELECTRONICS LLC**

2895 Greenspoint Parkway, Suite 200  
Hoffman Estates, IL 60169 U.S.A  
Tel: (1) 847-843-7900/Fax: (1) 847-843-7787

**OMRON ASIA PACIFIC PTE. LTD.**

No. 438A Alexandra Road # 05-05/08 (Lobby 2),  
Alexandra Technopark,  
Singapore 119967  
Tel: (65) 6835-3011/Fax: (65) 6835-2711

**OMRON (CHINA) CO., LTD.**

Room 2211, Bank of China Tower,  
200 Yin Cheng Zhong Road,  
PuDong New Area, Shanghai, 200120, China  
Tel: (86) 21-5037-2222/Fax: (86) 21-5037-2200

**Authorized Distributor:**

© OMRON Corporation 2018 All Rights Reserved.  
In the interest of product improvement,  
specifications are subject to change without notice.

**Cat. No. P707-E1-01**

1018-(1018)